

# PIXMA nyomtatók, multifunkciós eszközök kellékanyag táblázata

## Nyomtatókazetták és tintapatronok

	40 Black PG-40	41 Color CL-41	50 Black PG-50 High Yield	51 Color CL-51 High Yield	52 Photo CL-52	5 PGBK PGI-5BK	8 BK CLI-8BK	8 C CLI-8C	8 M CLI-8M	8 Y CLI-8Y	8 PC CLI-8PC	8 PM CLI-8PM	15 Black BCI-15 Black	16 Color BCI-16 Color	6 BK BCI-6 BK	6 Cyan BCI-6 C	6 Magenta BCI-6 M	6 Yellow BCI-6 Y	6 Black/PC BCI-6 PC	6 Black/PM BCI-6 PM	6 Red BCI-6 R	6 Green BCI-6 G	3e Black BCI-3eBK	24 Black BCI-24 Black	24 Color BCI-24 Color	
<b>PIXMA aktuális modellek</b>	PG-40	CL-41	PG-50 High Yield	CL-51 High Yield	CL-52	PGI-5BK	CLI-8BK	CLI-8C	CLI-8M	CLI-8Y	CLI-8PC	CLI-8PM	BCI-15 Black	BCI-16 Color	BCI-6 BK	BCI-6 C	BCI-6 M	BCI-6 Y	BCI-6 PC	BCI-6 PM	BCI-6 R	BCI-6 G	BCI-3eBK	BCI-24 Black	BCI-24 Color	
PIXMA MP800						■	■	■	■	■																
PIXMA MP500						■	■		■	■																
PIXMA MP450	■	■	■	■																						
PIXMA MP170	■	■	■	■																						
PIXMA MP150	■	■	■	■																						
PIXMA MP780															■	■	■	■						■		
PIXMA iP8500															■	■	■	■								
PIXMA iP90													■	■												
PIXMA iP6600D							■	■	■	■	■	■														
PIXMA iP6220D		■		■	■																					
PIXMA iP6210D		■		■	■																					
PIXMA iP5200						■	■	■	■	■																
PIXMA iP5200R						■	■	■	■	■																
PIXMA iP4200						■	■	■	■	■																
PIXMA iP2200	■	■	■	■																						
PIXMA iP1600	■	■																								
<b>PIXMA korábbi modellek</b>																										
PIXMA iP1000 / iP1500																								■	■	
PIXMA iP2000																								■	■	
PIXMA iP3000																								■	■	
PIXMA iP4000 / iP4000R															■	■	■	■	■					■	■	
PIXMA iP5000															■	■	■	■	■					■	■	
PIXMA iP6000D															■	■	■	■	■	■						
PIXMA iP8500															■	■	■	■	■	■	■	■				
PIXMA MP110 / MP130																									■	■
PIXMA MP750 / MP780															■	■	■	■	■					■	■	