

ASUSTEK COMPUTER INC.

ASUS Goes Mobile F7400 Series

Service Guide

F7400 Series
F7400 Series



ASUS

ASUS NOTEBOOK F7400 SERIES

Service Guide

© ASUSTek Computer Inc.
Product Marketing and Technical Support Div.
No. 150, Li-Te Rd., Peitou, Taipei, Taiwan, ROC.
Phone 886-2-894-3447 • Fax 886-2-895-9254

User's Notice

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

- Intel, LANDesk, and Pentium are registered trademarks of Intel Corporation.
- IBM and OS/2 are registered trademarks of International Business Machines.
- Symbios is a registered trademark of Symbios Logic Corporation.
- Windows and MS-DOS are registered trademarks of Microsoft Corporation.
- Soft Synthesizer is a trademark of the Yamaha Corporation.
- Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated.

The product name and revision number are both printed on the product itself. Manual revisions are released for each product design represented by the digit before and after the period of the manual revision number. Manual updates are represented by the third digit in the manual revision number.

For previous or updated manuals, BIOS, drivers, or product release information, contact ASUS at <http://www.asus.com.tw> or through any of the means indicated on the following page.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 1998 ASUSTeK COMPUTER INC. All Rights Reserved.

Product Name:	ASUS Notebook F7400 Series
Manual Revision:	1.0
Release Date:	September 1998

Technical Support Division

Table of Contents

1. ASUS F7400 Notebook Service Policy	1-1
ASUS Service Policy	1-2
ASUS Notebook Service Repair Center	1-3
U. S. A. Service Repair Center	1-3
Europe Service Repair Center	1-3
Taiwan Service Repair Center	1-3
China Service Repair Center	1-4
World Wide Service Channel	1-5
MCC Sequel - Japan	1-5
Location of Service Channel and Repair Center	1-6
How Can I Get Support	1-7
The online F7400 Installation Guide & Users Manual	1-7
The World Wide Web	1-7
The BBS	1-7
ASUS Technical Support	1-7
2. F7400 Series Key Components and Disassembly	2-1
ASUS F7400 Series Overview, Key Components and Modules	2-2
F7400 Overview	2-2
F7400 Key Components	2-3
Appropriate Tools for Assembly and Disassembly	2-10
F7400 Module Device Disassembly Procedure	2-11
Battery Module Removal	2-11
CD-ROM Module Removal and Disassembly	2-12
HDD Module Removal and Disassembly	2-13
F7400 System Disassembly Procedure	2-14
TFT LCD Module Removal	2-14
TFT LCD Module Disassembly	2-15
Keyboard and Heat Sink Plate Removal	2-17
VGA Module Removal	2-18

IMM MMC-2 Removal	2-18
Rear Door and DIMM Cover Removal	2-19
Top Case Removal	2-20
Power Board Module Removal	2-21
Main Board Removal	2-22
PCMCIA Socket Module Removal	2-23
IMM Bracket Removal	2-23
3. F7400 Series Assembly	3-1
F7400 Module Device Assembly Procedure	3-1
CD-ROM Module Assembly and Installation	3-2
HDD Module Assembly and Installation	3-3
Battery Module Installation	3-4
F7400 System Assembly Procedure	3-5
IMM Bracket Installation	3-5
PCMCIA Socket Module Installation	3-6
Main Board Installation	3-7
FDD Module and FDD Frame Installation	3-8
Power Board Module Installation	3-8
Top Case Installation	3-9
DIMM Cover and Rear Door Installation	3-10
IMM MMC-2 Installation	3-11
VGA Module Installation	3-11
Heat Sink Plate and Keyboard Installation	3-12
TFT LCD Module Assembly	3-13
TFT LCD Module Installation	3-14
4. Upgrade and Replacement	4-1
IMM MMC-2	4-2
What is IMM MMC-2	4-2
IMM MMC-2 Upgrade/Replacement	4-2
MPEG-2 Board Module (Optional)	4-3
56K Modem Board Module (Optional)	4-3
Memory Module	4-3
BIOS	4-4
EPROM Chip	4-4
Keyboard Plate Module	4-5

Hard Disk Drive Module	4-5
5. Technical Specification and Features of F7400	5-1
Main System	5-1
System Unit	5-1
I/O Unit	5-2
Accessories and Devices	5-5
Hard Disk Drive	5-5
14.1 inch TFT Display	5-10
CD-ROM Drive	5-12
DVD-ROM Drive	5-14
Floppy Drive	5-15
AC Power Adapter	5-17
Battery Pack	5-18
6. System Software Specification	6-1
System Resources Map	6-2
I/O Address	6-2
DMA Channel	6-2
Interrupt	6-3
Memory Map	6-3
Function Key Definition of F7400	6-4
Hot Key Definition	6-4
Status Icon indication on System Status Panel	6-5
BIOS POST Code	6-6
7. Regulatory and Certification Information	7-1
Regulatory Information	7-1
U. S. A.	7-1
Canada	7-2
Europe	7-2
Certification Information	7-3
PC97 Compliance	7-3
NSTL T2000 Compliance	7-3
