

# MB460 MFP, MB470 MFP, MB480 MFP

## User's Guide

# Copyright Information

---

Copyright © 2009 by Oki Data. All Rights Reserved

## Document Information

MB460 MFP, MB470 MFP, MB480 MFP User's Guide

P/N 59318901

Revision 1.1

October, 2009

## Disclaimer

Every effort has been made to ensure that the information in this document is complete, accurate, and up-to-date. The manufacturer assumes no responsibility for the results of errors beyond its control. The manufacturer also cannot guarantee that changes in software and equipment made by other manufacturers and referred to in this guide will not affect the applicability of the information in it. Mention of software products manufactured by other companies does not necessarily constitute endorsement by the manufacturer .

While all reasonable efforts have been made to make this document as accurate and helpful as possible, we make no warranty of any kind, expressed or implied, as to the accuracy or completeness of the information contained herein.

The most up-to-date drivers and manuals are available from the web site: <http://www.okiprintingsolutions.com>

## Trademark Information

Oki is a trademark of Oki Electric Industry Company Ltd.

Apple, Macintosh and Mac OS are registered trademarks of Apple Computers Inc.

Hewlett-Packard, HP, and LaserJet are registered trademarks of Hewlett-Packard Company.

Microsoft, MS-DOS and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Other product names and brand names are registered trademarks or trademarks of their proprietors.

## Emergency first aid

Take care with toner powder:

**If swallowed**, give small amounts of cold water and seek medical attention. **DO NOT** attempt to induce vomiting.



If inhaled, move the person to an open area for fresh air. Seek medical attention.

If it gets into the eyes, flush with large amounts of water for at least 15 minutes keeping eyelids open. Seek medical attention.

Spillages should be treated with cold water and soap to help reduce risk of staining skin or clothing.

# Contents

---

<b>About this Guide</b> . . . . .	<b>6</b>	Managing the address book . . . . .	69
<b>Notes, Cautions and Warnings</b> . . . . .	<b>7</b>	Adding an email address entry . . . . .	69
<b>Introduction</b> . . . . .	<b>8</b>	Deleting an email address entry . . . . .	70
<b>Overview</b> . . . . .	<b>10</b>	Modifying an email address entry . . . . .	70
Front View . . . . .	10	Adding a group entry . . . . .	71
Rear View . . . . .	12	Deleting a group address entry . . . . .	71
Control Panel . . . . .	13	Modifying a group address entry . . . . .	72
Character Switching . . . . .	16	<b>Access Control</b> . . . . .	<b>73</b>
Changing the Display Language . . . . .	17	Enabling Access Control . . . . .	73
<b>Getting Started</b> . . . . .	<b>18</b>	Logging in . . . . .	73
Releasing the Scanner Lock . . . . .	18	Logging out . . . . .	74
Power Save Mode . . . . .	18	Operation time-out . . . . .	74
Switching Off . . . . .	19	<b>Operation</b> . . . . .	<b>75</b>
Installing Drivers and Utilities . . . . .	20	Loading document(s) . . . . .	75
Windows: Installing the Twain (Scanner) Driver	20	Placing document(s) in the ADF . . . . .	75
and Printer Drivers . . . . .	20	Placing document(s) on the glass . . . . .	77
Mac OS X: Installing the Printer Driver . . . . .	23	Copying . . . . .	78
Fax Driver: Windows Only . . . . .	24	Basic operation . . . . .	78
MFP Setup Tool: Windows Only . . . . .	25	Advanced operation . . . . .	78
Actkey Utility: Windows Only, USB Only . . . . .	25	Scanning . . . . .	80
Paper Recommendations . . . . .	28	Basic Operation . . . . .	80
Tray 1 . . . . .	28	Scan To Email . . . . .	80
Multi Purpose Tray . . . . .	29	Scan to Network PC . . . . .	82
Face Down Stacker . . . . .	30	Scan to PC . . . . .	82
Face Up Stacker . . . . .	30	Faxing (MB470 MFP & MB480 MFP):	
Duplex Unit . . . . .	30	Basic operation . . . . .	85
Loading Paper . . . . .	31	Searching the phone book . . . . .	85
Cassette Trays . . . . .	31	Sending a Fax . . . . .	86
Loading Paper: Manual Feed Tray (MB460 MFP) . . . . .	35	Faxing (MB470 MFP & MB480 MFP):	
Loading Paper: Multi Purpose Tray (MB470 MFP & MB480 MFP) . . . . .	37	Advanced operation . . . . .	87
<b>Configuring your machine</b> . . . . .	<b>40</b>	Changing the Fax Quality (Mode) . . . . .	87
Minimum configuration requirements . . . . .	40	Adjusting Density . . . . .	87
To send faxes (MB470 MFP & MB480 MFP): . . . . .	40	Document Size . . . . .	87
To send e-mails: . . . . .	40	Fax Receiving . . . . .	88
To file document(s) via intranet . . . . .	40	Faxing (MB470 MFP & MB480 MFP):	
Pre-configuration information . . . . .	40	Printing Reports . . . . .	90
General . . . . .	40	Printing a fax activity report . . . . .	90
Fax set up (MB470 MFP & MB480 MFP) . . . . .	41	Printing transmission reports . . . . .	91
Network set up . . . . .	41	Faxing (MB470 MFP & MB480 MFP):	
Internet communication features . . . . .	43	Sending a Fax from your PC . . . . .	92
Configuration . . . . .	45	Using the Phone Book . . . . .	94
. . . from the web page . . . . .	46	<b>Printer Settings in Windows</b> . . . . .	<b>97</b>
. . . from the setup tool . . . . .	47	Printing preferences in Windows applications . . . . .	97
. . . from the control panel . . . . .	48	PCL emulation . . . . .	98
The Printer Menu . . . . .	49	Setting from Windows control panel . . . . .	102
Setting the fax facility		PS emulation (MB470 MFP & MB480 MFP) . . . . .	106
(MB470 MFP & MB480 MFP) . . . . .	64	Settings from the Control Panel . . . . .	110
Initial set up . . . . .	64	2-sided (duplex) printing . . . . .	111
Advanced set up . . . . .	65	To carry out Duplex Printing: . . . . .	111

<b>Printer settings in Mac OS X . . . . .</b>	<b>112</b>	<b>Troubleshooting . . . . .</b>	<b>153</b>
PCL emulation . . . . .	112	Clearing paper jams . . . . .	153
Setting printing options . . . . .	112	In the scanner ADF section... . . . .	153
Saving driver settings . . . . .	113	In the printer section... . . . .	154
Changing the Default Printer and Paper Size. . . . .	114	Dealing with unsatisfactory printing . . . . .	163
Page setup options . . . . .	114	Dealing with unsatisfactory copying . . . . .	164
Print Options. . . . .	115	Fax problem checklist	
Paper Handling . . . . .	118	(MB470 MFP & MB480 MFP) . . . . .	165
Cover page. . . . .	119	<b>Specifications. . . . .</b>	<b>167</b>
Duplex . . . . .	119	General . . . . .	167
Effects . . . . .	121	<b>Appendix A - Moving and transporting . . .</b>	<b>176</b>
Printer setup options . . . . .	122	Moving your MFP . . . . .	176
Printer options . . . . .	122	Transporting your MFP. . . . .	176
Print control . . . . .	123		
Summary . . . . .	123		
PS emulation (MB470 MFP & MB480 MFP) . . . . .	124		
Copies & pages . . . . .	124		
Layout . . . . .	124		
Scheduler . . . . .	124		
Paper handling . . . . .	124		
Cover page. . . . .	124		
Error Handling . . . . .	125		
Paper Feed . . . . .	125		
Printer Features . . . . .	126		
Cancelling a print job . . . . .	128		
<b>Overlays and Macros (Windows only). . . .</b>	<b>129</b>		
What are overlays and macros? . . . . .	129		
Creating PostScript overlays. . . . .	129		
Creating the overlay image. . . . .	129		
Create and download the project. . . . .	130		
Test printing the overlay . . . . .	130		
Defining overlays . . . . .	131		
Printing with PostScript overlays . . . . .	131		
Creating PCL Overlays . . . . .	132		
Creating the overlay image. . . . .	132		
Create and download macros . . . . .	133		
Test printing the macro . . . . .	133		
Defining overlays . . . . .	134		
Printing with PCL overlays . . . . .	134		
<b>Maintenance . . . . .</b>	<b>136</b>		
Consumables . . . . .	136		
Replacing consumable items . . . . .	137		
Toner cartridge replacement. . . . .	137		
Image drum replacement. . . . .	142		
Cleaning . . . . .	147		
...the unit casing . . . . .	147		
...the paper path in the ADF . . . . .	147		
... the underside of the ADF . . . . .	148		
...the document glass . . . . .	149		
...the LED head . . . . .	150		
<b>Installing options . . . . .</b>	<b>152</b>		
Installing options order numbers . . . . .	152		
Installation procedure . . . . .	152		

# About this Guide

---

---

**Note**

Images used in this manual may include optional features that your product does not have installed.

---

This guide is part of a suite of printed and online documentation provided to help you become familiar with your unit and to make the best use of its many features.

# Notes, Cautions and Warnings

---

---

## **Note**

A note provides additional information to supplement the main text.

---

## **Caution!**

**A caution provides additional information which, if ignored, may result in equipment malfunction or damage.**

## **Warning!**

**A warning provides additional information which, if ignored, may result in a risk of personal injury.**

For the protection of your unit, and in order to ensure that you benefit from its full functionality, this model has been designed to operate only with genuine original toner cartridges. Any other toner cartridge may not operate at all, even if it is described as “compatible”, and if it does work, your product's performance and print quality may be degraded.

Specifications are subject to change without notice.

# Introduction

---

Congratulations on choosing this Multi Function Product (MFP). It is designed with advanced features, to give you clear and crisp black and white pages at high speed on a range of office print media.

With this MFP, you can instantly scan paper-based documents and deliver the electronic image to various destinations including e-mail addresses, printers, ftp servers, fax machines or someone else's computer on the network.

Your MFP includes these features:

- **Digital copying**  
An intuitive control panel, makes digital copying fast and easy.
- **Fast Copy Speed**  
Up to 22 copies per minute Letter (21 copies per minute A4 SEF) in black and white for fast and efficient copying.
- **Up to 600 x 600 dpi (dots per inch) copy resolution.**
- **Actkey utility** (Windows only)  
Enables the MFP to receive one key touch commands from a locally connected computer ("pull scan").
- **Scan to E-mail**  
Connected to an Ethernet network and a SMTP server, this MFP allows you to transmit document(s) over the internet via e-mail. With a touch of the e-mail button and the selection of your recipients' e-mail addresses, the document(s) is/are first scanned and converted into an image file, and then transmitted to remote recipients within minutes.
- **Scan to Network PC**  
Allows you to send scanned documents (PDF, TIFF and JPEG file formats) to a server or a personal computer's file folder over an intranet with FTP (File Transfer Protocol), CIFS (Common Internet File System) protocol. The scan to filing feature removes the need for the mail server to handle large attachments.
- **Network/PC Printing**  
When connected to a Network, the MFP is able to perform network or PC printing.
- **Multiple Pages Sending**  
With the Auto Document Feeder (ADF), the MFP allows a stack of up to 50 page document(s) to be continuously scanned.
- **Faxing (MB470 MFP & MB480 MFP)**  
An intuitive control panel, makes direct faxing fast and easy.
- **Advanced Fax Transmission and Reception**  
Includes delayed transmissions and sending to multiple locations.
- **Address Book/Profiles Managing**  
This provides a convenient way to manage all the e-mail addresses and profiles (filing destinations).

- **MFP Setup Tool Utility**  
Allows you to create up to 100 e-mail addresses and several filing destinations to manage your document.
- **Print Resolution**
  - 600 x 2400dpi (dots per inch) for MB460 MFP.
  - 1200 x 1200dpi for MB470 MFP and MB480 MFP .
- **Duplex Printing**  
Automatic two-sided (duplex) printing for economical use of paper and compact printing of larger documents.
- **High speed USB 2.0 interface**
- **Emulations**  
Standard PCL6, PCL5e and PostScript 3 for MB470 MFP and MB480 MFP.
- **Paper Handling**  
250 sheets (75 g/m<sup>2</sup>) for MB460 MFP and MB470 MFP and 530 sheets (75 g/m<sup>2</sup>) for MB480 MFP.
- **Template Manager Utility for Windows**  
Enables the design and print of business cards, banners, labels with ease.


The following optional features are available:

- Additional memory, to allow printing of more complex pages.
- One additional paper tray for loading a further 530 sheets.


# Overview

---

## Front View




1.	<b>Output stacker, face down</b> Standard printed copy delivery point. Holds up to 150 sheets of 20-lb. US Bond (75 g/m <sup>2</sup> ) paper.
2.	<b>Top cover release button</b> Press to open.
3.	<b>Multi purpose tray release handle</b> Pull to open.
4.	<b>Multi purpose tray</b> Used for feeding heavier paper stocks, envelopes and other special media. MB460 MFP: Manual feeding of single sheets. MB470 MFP & MB480 MFP: Holds up to 50 sheets of 20-lb. US Bond (75 g/m <sup>2</sup> ) paper. Also has an extendable paper support.




5.	<p><b>Paper tray</b>            MB460 MFP/MB470 MFP: Holds up to 250 sheets of 20 lb. US Bond (75g/m<sup>2</sup>) paper.            MB480 MFP: Holds up to 530 sheets of 20 lb. US Bond (75g/m<sup>2</sup>.)</p>
6.	<p><b>Paper level lever</b>            To visually indicate the paper level in the tray.</p>
7.	<p><b>ON/OFF power switch</b>            Refer to "Switching Off" on page 19 for details.</p>
8.	<p><b>Scanner Bed</b></p>
9.	<p><b>ADF ( Automatic Document Feed) unit</b></p>
10.	<p><b>ADF (Automatic Document Feed) paper tray</b>            Holds up to 50 sheets of letter/A4 size paper, 20 lb. US Bond (75 g/m<sup>2</sup>).</p>
11.	<p><b>Document cover</b></p>
12.	<p><b>Control panel</b>            With LCD and operator buttons.            One touch key (shown) is only for MB470 MFP &amp; MB480 MFP. Refer to "Control Panel" on page 13.</p>

## Rear View




13.	<b>Access panel</b> Allows access to install optional memory.
14.	<b>Duplex unit</b> Provides automatic two-sided printing.
15.	<b>Rear output cover (closed) (face up stacker)</b> This is mainly used for heavy print media. When used in conjunction with the multi purpose feed tray, the paper path through the MFP is essentially straight. This avoids bending the print media around curves in the paper path.
16.	<b>AC power socket</b>
17.	<b>Parallel connector</b>
18.	<b>USB connector</b>
19.	<b>Test switch</b>
20.	<b>Network connection</b>
21.	<b>Line connection</b> (MB470 MFP & MB480 MFP) For connecting the machine to the telephone line. <b>Tel connection</b> (MB470 MFP & MB480 MFP) For connecting a telephone handset (if required).


# Control Panel



1.	<p><b>Key Pad</b></p> <p>Used to enter numbers, upper-case/lower-case letters and symbols in the Entry Line. Refer to "Character Switching" on page 16 for further details.</p>
2.	<p><b>Left Key</b></p> <p>When in Switching mode: Returns the display to the Function Selection screen or Scan Sub Function Selection screen from the Stand-by screen.</p> <p>When Setting up: Increments the value of the tree structure.</p>
3.	<p><b>Down Key</b></p> <p>When setting up or in switching mode: Moves the cursor down.</p>
4.	<p><b>Right Key</b></p> <p>When in Switching mode:</p> <ul style="list-style-type: none"> <li>• Used to confirm the Mode selected.</li> <li>• Used to start Push scan (if push scan is selected, the executing Push Scan screen is displayed.)</li> </ul> <p>When Setting up:</p> <ul style="list-style-type: none"> <li>• Decrements the value of the tree structure.</li> </ul>
5.	<p><b>Up Key</b></p> <p>When setting up or in Switching mode: Moves the cursor up.</p>



6.	<p><b>Enter Key</b></p> <p>When in Switching mode:</p> <ul style="list-style-type: none"> <li>• Used to confirm the Mode selected.</li> <li>• Used to start Push Scan (If Push scan is selected, the Executing Push scan screen is displayed.)</li> </ul> <p>When Setting up:</p> <ul style="list-style-type: none"> <li>• Increases/decreases the value of the tree structure.</li> </ul> <p>When entering Pin ID:</p> <ul style="list-style-type: none"> <li>• Used to confirm the PIN ID entered.</li> </ul> <p>When in Error/Warning State</p> <ul style="list-style-type: none"> <li>• Used to recover.</li> </ul>
7.	<p><b>One Touch Key Panel (MB470 MFP &amp; MB480 MFP only)</b></p> <p>The One Touch keys (7a) are used to dial numbers from #00 to #09 that you have programmed in as fax numbers.</p> <p>The shift key (7b) switches between numbers from 00 to 04 and numbers from 05 to 09.</p>
8.	<p><b>Start Button:</b></p> <ul style="list-style-type: none"> <li>• Press to execute the function selected (Copy, Scan, etc.).</li> <li>• Press to recover from Error/Warning states.</li> </ul>



9.	<b>Stop Button:</b> <ul style="list-style-type: none"><li>• Stops the function being executed (Copy, Scan, etc._).</li><li>• Cancels a Print job.</li></ul>
10.	<b>Liquid Crystal Display (LCD):</b> 128 x 64 dots.

# Character Switching

Numbers, upper and lower case letters and symbols can be entered using the keypad. Press the key multiple times to switch between characters.

The example below is based on English being the display language:

	To scan through the choices for each key, you must press the key rapidly: within 2 seconds of the previous press.
1	<b>1 → 1</b>
2	<b>a → b → c → A → B → C → 2</b>
3	<b>d → e → f → D → E → F → 3</b>
4	<b>g → h → i → G → H → I → 4</b>
5	<b>j → k → l → J → K → L → 5</b>
6	<b>m → n → o → M → N → O → 6</b>
7	<b>p → q → r → s → P → Q → R → S → 7</b>
8	<b>t → u → v → T → U → V → 8</b>
9	<b>w → x → y → z → W → X → Y → Z → 9</b>
0	<b>SP (space) → 0 → SP (Space)</b>
*	<b>@ → * → a</b>
#	<b>. → _ → - → P → SP (space) → + → ! → " → \$ → % → &amp; → ` → ( → ) → , → / → : → ; → &lt; → = → &gt; → ? → [ → £ → ] → ^ → #</b>

## Changing the Display Language

The default language used by your MFP for display messages and for report printing is English. If required, this can be changed using the Panel Language Setup utility.

- English
- Canadian French
- Latin American Spanish
- Brazilian Portuguese

---

### **Note**

See the information enclosed on the CD-ROM included with your unit (the Panel Language Setup Utility) for the procedure for changing the language.

---

# Getting Started


---

## Releasing the Scanner Lock

**Caution!**

Make sure the scanner is in the UNLOCKED position before operating.

1. Open the document cover.
2. Move the scan lock lever (1) to the UNLOCKED position.



## Power Save Mode

If you do not use the MFP for a while, the machine will enter the power save mode to control the power consumption of the device.

# Switching Off

***Caution!***

**Do not turn off the power switch suddenly as this may damage your MFP.**

1. Press the down arrow button on the control panel to highlight Menu. Press Enter.
2. Press the down arrow button on the control panel to highlight System Shutdown. Press Enter.
3. Press Enter to execute.
4. At the prompt, turn the power switch OFF.

# Installing Drivers and Utilities

Your machine is supplied with the following drivers:

- TWAIN (scanner) driver: Windows only, USB only
- Printer driver: PCL5e (all models), PCL 6 (all models), PostScript3 (MB470 MFP & MB480 MFP only)
- Fax driver: Windows only, MB470 MFP & MB480 MFP only

---

## Note

You must be logged on as an administrator or a member of the Administrators group in order to complete this procedure. If your computer is connected to a network, network policy settings may also prevent you from completing this procedure.

---

The MFP is a “dual device” - Windows sees it as a scanner and a printer. Therefore, you must install two different drivers; the TWAIN (scanner) driver and the printer driver.

The installation instructions below refer to USB connection. For network connection details refer to the Setup/Reference Guide.

If you are running Windows Server 2003 or Server 2008, you may need to follow these steps to ensure WIA service starts when using the TWAIN driver and Actkey Utility.

1. Click Start > Administrative Tools > Services.
2. Double-click Services.
3. Double-click Windows Image Acquisition (WIA).
4. From the Startup type menu, select Automatic.
5. Under Service status, click Start.
6. Click OK.

## Windows: Installing the Twain (Scanner) Driver and Printer Drivers

### TWAIN Driver: Pull versus Push Scanning

Pull Scanning = initiating a scan from your computer via software.

Push Scanning: initiating a scan by pressing a button on the MFP's front panel

The TWAIN driver is used for “Pull Scanning”. The TWAIN driver only works via USB connections. This means it's not possible to control the scanner over the network from your computer.

### Installing the Drivers

There are two ways of installing the drivers:

- Oki Driver Installer Program (recommended method)
- Plug and Play (USB only)

### Oki Driver Installer Installation

Before powering up the printer

1. Run the Oki driver installer program from the CD-ROM supplied with your unit.
2. Plug in the printer and switch it on.

*Windows completes the installation of the TWAIN and printer drivers automatically.*

### Plug and Play Installation

When the MFP is plugged into a PC using a USB cable, you'll be prompted to install two different drivers; the TWAIN (scanner) driver first and then the printer driver.

1. Attach the printer to a USB port on your computer.
2. Switch on the Printer.
3. Insert the Drivers & Utilities CD supplied with you unit.

---

#### Note7

If the CD runs automatically, cancel the dialog box.


---

The 'New Hardware Found' screen displays.




If you do not see the 'New Hardware Found' screen, please check that the power and USB cables are connected properly, and the printer is switched on.

#### 4. Install the TWAIN driver first



## 5. Next install the Printer driver



## Mac OS X: Installing the Printer Driver

The information in this section is based on Mac OS X Leopard (10.5). Other versions may appear slightly different, but the principles are the same.

1. Insert the CD-ROM and run the Oki driver installer program.
2. Follow the on-screen instructions to install the printer driver.
3. Attach the printer to a USB port on your computer.
4. Switch on the printer.
5. Choose Apple Menu > System Preferences > Print & Fax.
6. If the printer is already in the list of printers, click "-" to remove it.


---

### Note

This is necessary as Leopard may not be using the correct Oki printer driver files.

---

7. Click “+” to add a new printer.
8. Click More Printers.
9. Choose OKI USB from the pop-up menu.



10. Select your printer model and click Add.  
*The printer is added to the list of printers.*
11. Restart your computer.

---

**Note**

Please refer to the readme file on the CD for details on installing the appropriate Macintosh driver.

MB470 MFP & MB480 MFP: You can choose PCL or PS driver on the Macintosh Operating System.

---

## Fax Driver: Windows Only

The fax driver allows you to send faxes directly from your computer without printing the document first. With the fax driver you are sending the fax data from your computer to the MFP, and then the MFP automatically sends the document.

Windows XP has built-in fax support: you can use your computer's modem to send faxes directly from your computer.


### Installing the Fax Driver

This is installed as part of the Oki driver installer wizard.

## MFP Setup Tool: Windows Only

Installation of the MFP setup utility is optional and can be found on the CD under the Utilities folder.

The MFP setup tool can discover the devices over USB or network connections. To discover, select File > Printer Discovery.



The MFP setup tool allows you to configure your unit. Refer to "Pre-configuration information" on page 40 for detailed instructions.

## Actkey Utility: Windows Only, USB Only

---

### Note

You must have the TWAIN driver installed.

---

The Actkey utility enables the unit to receive one key touch commands from a locally connected computer.

Installation of the Actkey utility is optional. It is on the Driver/Utilities CD under the Utilities folder.

Information on using the Actkey utility can be found in "Scan to PC" on page 82.

### Setting up the Actkey Utility


1. Install the Actkey utility from the CD:

Set-up will place an "Actkey" icon on your desktop.

2. Double-click this icon to open the Actkey console.



3. Select Options > Button Settings. The following screen displays.



4. Select the function you want to set in section (1).
  5. Set the parameters for this function in section (2).
  6. When you have completed settings, press OK (3).
- The Utility returns to the Actkey console.

7. To use Actkey in Local PC mode (i.e. push scanning), it must be set as the program to handle scanner events:


---

**Note**

The following example uses Windows XP. The steps may vary if you are using any other operating system, but the principle is the same.

---

- a. Select Start > Control Panel.
- b. Double-click Scanners and Cameras.
- c. Right-click the MFP icon and click Properties.
- d. Select the **Events** tab.
- e. Choose an event from the Select an event drop-down menu.
- f. In the Actions field, click Start this program and choose ActKey from the dropdown menu.
- g. Click Apply.
- h. Repeat steps e to g for each event, e.g. Scan to Application, E-mail, Folder and PC-Fax.
- i. Click OK to confirm.



# Paper Recommendations

Your MFP will handle a variety of print media, including a range of paper weights and sizes, transparencies and envelopes. This section provides general advice on choice of media, and explains how to use each type.

**Standard Paper:** The best performance will be obtained when using standard 60 to 120 g/m<sup>2</sup> paper designed for use in copiers and laser printers.

**Not Recommended:** Use of heavily embossed or very rough textured paper is not recommended.

Letterhead Stationery: Pre-printed stationery can be used, but the ink must not offset when exposed to the high fuser temperatures used in the printing process.

## Tray 1

The paper tray can handle paper weights of 16 to 32 lb. US Bond (60 to 120 g/m<sup>2</sup>).

Size	Dimensions	Weight (US Bond g/m <sup>2</sup> )
Letter	8.5 x 11 inches	Light • 16-17 lb. US Bond • 60 - 63 g/m <sup>2</sup> Medium Light • 18 lb. US Bond • 64 - 74 g/m <sup>2</sup> Medium • 20-24 US Bond • 75 - 89 g/m <sup>2</sup> Medium Heavy • 24-28 lb. US Bond • 90 - 104 g/m <sup>2</sup> Heavy • 28-32 lb. US Bond • 105 - 120 g/m <sup>2</sup>
Legal 13	8.5 x 13 inches	
Legal 13.5	8.5 x 13.5 inches	
Legal 14	8.5 x 14 inches	
Executive	7.25 x 10.5 inches	
A5	148 x 210mm	
B5	182 x 257mm	
A4	210 x 297mm	

---

### Note

The optional second tray can also handle the above paper sizes except for Statement.

---

If you have identical paper stock loaded in another tray (the optional 2nd or the multi purpose tray) you can have the MFP switch to another tray when the current tray runs out of paper. When printing from Windows applications, this function is enabled in the driver settings. When printing from other systems, this function is enabled in the Printer menu.

## Multi Purpose Tray

The multi purpose tray can handle the same media sizes as the cassette trays but in weights from 60g/m<sup>2</sup> up to 163g/m<sup>2</sup>. For very heavy paper stock, use the face up (rear cover) paper stacker. This ensures that the paper path through the MFP is almost straight.

Use the multi purpose tray for printing on envelopes and transparencies. Up to 50 sheets of transparencies or 10 envelopes can be loaded at one time, subject to a maximum stacking depth of 10 mm for Xxxxxdn and Xxxxxdtn and one sheet at a time for Xxxxxn.

Size	Dimensions	Weight
Letter	8.5 x 11 inches	Light <ul style="list-style-type: none"> <li>• 16-17 lb.US Bond</li> <li>• 60-63g/m<sup>2</sup></li> </ul> Medium Light <ul style="list-style-type: none"> <li>• 18 lb. US Bond</li> <li>• 64 - 74 g/m<sup>2</sup></li> </ul> Medium <ul style="list-style-type: none"> <li>• 20-24 US Bond</li> <li>• 75 - 89 g/m<sup>2</sup></li> </ul> Medium Heavy <ul style="list-style-type: none"> <li>• 24-28 lb. US Bond</li> <li>• 90 - 104 g/m<sup>2</sup></li> </ul> Heavy <ul style="list-style-type: none"> <li>• 28-32 lb. US Bond</li> <li>• 105 - 120 g/m<sup>2</sup></li> </ul>
Legal 13	8.5 x 13 inches	
Legal 13.5	8.5 x 13.5 inches	
Legal 14	8.5 x 14 inches	
Executive	7.25 x 10.5 inches	
Statement	5.5 x 8.5 inches	
A6	105 x 140 mm	
A5	148 x 210 mm	
A4	210 x 297 mm	
B5	182 x 257 mm	
Com-9 Envelope	98,4 x 225.4 mm	
Com-10 Envelope	104,7 x 241,3 mm	
Monarch Envelope	98.4 x 190.5 mm	
DL Envelope	109.9 x 219.9 mm	
C5 Envelope	162 x 229 mm	
C6	114 x 162 mm	
Custom Sizes:		
Width	3.4 - 8.5 inches 86 - 216 mm	
Length	5.5 - 14 inches 140 - 355.6 mm	

### Note

Label mode must be selected in the printer driver, if you want to print on heavy media which exceeds 120 g/m<sup>2</sup>.

## Envelopes

***Caution!***

Envelopes should be free from twist, curl or other deformations. They should also be of the rectangular flap type, with glue that remains intact when subjected to hot roll pressure fusing used in this type of printer. Window envelopes are not suitable.

## Transparencies

***Caution!***

Do not use transparencies designed for use in color laser printers and photocopiers.

Recommended type is CG3300 by 3M (A4 or Letter size).

## Labels

***Caution!***

Labels should cover entire carrier sheet. The carrier sheet or adhesive must not be exposed to any part of the printer.

## Face Down Stacker

The face down stacker on the top of the MFP can hold up to 150 sheets of 64g/m<sup>2</sup> standard paper and can handle paper stocks up to 120g/m<sup>2</sup>. Pages printed in reading order (page 1 first) will be sorted in reading order (last page on top, facing down).

## Face Up Stacker

For the face up stacker, cover at the rear of the MFP should be opened when required for use. In this condition paper will exit via this path, regardless of driver settings.

Always use this stacker and the multi purpose feeder for heavy paper stocks.


## Duplex Unit

The duplex unit provides automatic two-sided printing on the same range of paper sizes as tray 2 (i.e. all cassette sizes except A6), using paper stocks from 75-105g/m<sup>2</sup>.


# Loading Paper

## Cassette Trays


1. Remove the paper tray from the MFP.




2. Adjust the rear stopper (3) and paper guides (4) to the size of paper being used. For loading A4 or Legal size paper, push the lever in the arrow direction (b) and extend the paper tray using the rear paper stopper.



3. Fan the paper to be loaded at the edges (1) and in the middle (2) to ensure that all sheets are properly separated, then tap the edges of the stack on a flat surface to make it flush again (3).



4. Load paper short edge feed (SEF) (1) (for letterhead paper load face down with top edge towards the front of the paper tray) up to mark (a). The paper level indicator (2) provides a visual indication of how much paper is left in the tray.



---

**Note**

For letter head stationery, load the paper face down with the top edge towards the front of the paper tray

---

5. If required, set the correct media type in the Printer menu. .

---

**Note**


To prevent paper jams:

- Do not leave space between the paper and the guides and rear stopper.
  - Do not overfill the paper tray. Capacity depends on the type of paper stock.
  - Do not use damaged paper.
  - Do not load paper of different sizes or types at the same time.
  - Close the paper tray gently.
  - Do not pull the paper tray out during printing (except as described below for the 2nd tray)
  - If you have two trays (optional second tray fitted) and you are printing from the 1st (upper) tray, you can pull out the 2nd (lower) tray during printing to reload it. However, if printing from the 2nd tray, do not pull out the 1st tray. This will cause a paper jam.
  - For face down printing, make sure the face up (rear cover) stacker is closed (the paper exits from the top of the MFP). Stacking capacity is approximately 150 sheets, depending on paper weight.
  - For face up printing, make sure the face up (rear cover) stacker is open Always use the face up (rear cover) stacker for heavy paper (card stock, etc.).
- 

***Caution!***


**Do not open or close the rear paper exit while printing as it may result in a paper jam.**

6. Replace the tray in the MFP.




## Loading Paper: Manual Feed Tray (MB460 MFP)

1. Open the manual feed tray (1).




2. Press gently down on the paper platform (2) to ensure it is latched down.

3. Adjust the paper guides (3) to the size of paper being used.



4. Load a sheet of paper in the manual feeder, then press inwards to release the paper platform, so that the paper is lifted and gripped in place.




- For single-sided printing on letterhead stationery, load the paper into the tray with the pre-printed side up and the top edge into the MFP.

- For two-sided (duplex) printing on letterhead stationery, load the paper with the pre-printed side down and the top edge away from the MFP.
- Envelopes should be loaded face up with the top edge to the left and the short edge into the MFP. Do not select duplex printing on envelopes.
- Load transparencies face up and top edge into the MFP.

5. Set the correct paper size for the manual tray in the Printer menu.


## Loading Paper: Multi Purpose Tray (MB470 MFP & MB480 MFP)

1. Open the multi purpose tray (1). Fold out the paper support (a)




2. Press gently down on the paper platform (2) to ensure it is latched down.

- 3.** Adjust the paper guides (3) to the size of paper being used. Do not exceed the paper capacity of about 50 sheets or 10 envelopes. Maximum stacking depth is 10 mm (about 3/8-inch).



- 4.** Press the tray latch button (4) inwards to release the paper platform, so that the paper is lifted and gripped in place.



- For single-sided printing on headed paper load the paper into the multi purpose tray with pre-printed side up and top edge into the MFP.
  - For two-sided (duplex) printing on headed paper load the paper with pre-printed side down and the top edge away from the MFP.
  - Envelopes should be loaded face up with top edge to the left and short edge into the MFP. Do not select duplex printing on envelopes.
  - Load transparencies face up and top edge into the MFP.
- 5.** Set the correct paper size for the multi purpose tray in the Printer menu.
- a. Press the Down Arrow key repeatedly until Menu appears, then press Enter.
  - b. Navigate: Menu Function > Print Menu > Tray Configuration >
    - (i) For MB460 MFP: Manual Feeder Config > Paper Size.
    - (ii) For MB470 MFP/MB480 MFP: MP Tray Config > Paper Size.

# Configuring your machine ---

## Minimum configuration requirements

To make the best of this MFP, the following configuration is required:

### To send faxes (MB470 MFP & MB480 MFP):

A PSTN telephone line connection.

### To send e-mails:

- TCP/IP network.
- A SMTP and an optional POP3 server.
- Default "From" Address (this MFP's Address).

### To file document(s) via intranet

- FTP or CIFS Protocol environment.
- Windows 2000, Windows XP, Windows Vista, Mac OS X or FTP server.

## Pre-configuration information

### General

Ensure that you have the relevant permission/PIN numbers before starting.

The factory set default passwords/PIN are:

Administrator	aaaaaa
PIN	000000
Network (webpage)	aaaaaa

---

#### Note

The administrator password and PIN should be changed and maintained by the system administrator.

---

## Fax set up (MB470 MFP & MB480 MFP)

Your MFP has to be set up properly to allow faxing from the machine. The following parameters must be set before using the fax function:

- Date and time
- Country code
- Local phone number
- Sender ID

See "Initial set up" on page 64 for details.

---

### Note

If you ran the Oki driver installer program from the CD-ROM you may have already set the time zone, date and time (Windows only) via the Panel Language Setup utility.

---

## Network set up

The MFP must also be set up properly on your network to perform scan to e-mail and other functions. In order for other network devices to find the MFP on the network, the following network parameters have to be set.

1. IP Address Set:
2. IP Address: . . . .
3. Subnet Mask: . . . .
4. Gateway Address: . . . .
5. DNS Server: . . . .
6. SMTP Server: . . . .
7. SMTP Port: 25
8. POP3 Server: . . . .
9. POP3 Port: 110

### Explanation:

1. IP Address Set:

Choose Auto to obtain IP/subnet/gateway addresses automatically from DHCP server. After changing setting from Manual to Auto, the MFP will automatically reboot the network card.

2. IP Address:

The Internet Protocol (IP) address assigned to your machine by your network administrator.

**3. Subnet Mask:**

The net mask address assigned by your network administrator.

**4. Gateway Address:**

The gateway IP address assigned by your network administrator.

**5. SMTP Server:**

The IP address of your SMTP Mail Server assigned by your network administrator.

**6. SMTP Port:**

The port number of your SMTP Mail Server.

**7. DNS Server:**

The IP address of DNS Server assigned by your network administrator.

**8. POP3 Server:**

The IP address of your POP3 server.

**9. POP3 Port:**

The port number of your POP3 Server.

Enter the DNS name, or IP and port number of your POP3 server if your mail server requires POP3 authentication, before sending e-mails from the machine.

---

**Note**

You must also set up the "From" details to allow e-mail sending.

---

---

## Notes

1. DHCP server: With DHCP (Dynamic Host Configuration Protocol), a host can automatically be given a unique IP address each time it connects to a network-making IP address management an easier task for network administrators. If the DHCP server is available from your network, you do not need to enter TCP/IP, subnet mask, gateway, and DNS information. Instead, this information will be automatically given for the MFP.
2. IP Address: An IP (Internet Protocol) address uniquely identifies a host connection to an IP network. System administrator or network designer assigns the IP address. The IP address consists of two parts, one identifying the network and the one identifying your node. The IP address is usually written as four numbers separated by periods. Each number can be zero to 255. For example, 10.1.30.186 could be an IP address.
3. SMTP: (Simple Mail Transfer Protocol) is the main communication protocol used to send and receive e-mail on the Internet.
4. DNS: (Domain Name System). The DNS server identifies hosts via names instead of IP addresses. If the DNS server is available on your network, you can enter the domain name instead of digits for your SMTP or POP3 servers, such as Pegasus.com.tw instead of 120.3.2.23.
5. POP3: POP3 is the latest Post Office Protocol 3, this is a service that stores and serves e-mails for various client machines that are not connected to the Internet 24 hours a day. E-mails are held in POP3 until you log on.

---

## Internet communication features

### Scan to e-mail

The MFP allows you to deliver your scanned document to e-mail addresses on the network. The document is first scanned and converted to a standard PDF, JPEG or TIFF file format and then transmitted to remote recipients simultaneously as an e-mail attachment.

When you send an e-mail to someone using this MFP, it uses Simple Mail Transfer Protocol (SMTP) to transfer your outgoing e-mails to your SMTP mail server, and then sends these e-mails to your recipients through the internet.

## Setting up an SMTP Server

1. Using the Down arrow key, scroll to Menu, then press Enter.
2. Using the Down arrow key, scroll to Admin setup, then press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Network Menu, then press Enter.
5. Using the Down arrow key, scroll to Mail Server Setup , then press Enter.
6. Press Enter to select SMTP server.
7. Press Enter.
8. Enter your IP address.

---

### Note

Numbers are entered using the keypad.

When a number is entered from the keypad, the number currently displayed is cleared and the number just entered is displayed as the first digit. When another number is entered, the first number entered moves to the left, and so on.

You can increment/decrement the digits using the UP/Down arrow keys.

---

9. To confirm, press the Enter key.

---

### Note

To cancel the IP address, press the **Stop** key until you exit the menu without saving the changes.

---

## Scan to NetworkPC

Via the intranet with FTP (File Transfer Protocol) or CIFS (Common Internet File System). The MFP allows you to save scanned documents directly to a designated server or to a personal computer on the network in a standard PDF, JPEG, or TIFF file format.

CIFS is the sharing system of Microsoft Windows. What is unique about this filing function is that it allows all corporate users to share one machine to send documents to each file folder on a designated server or individual computer.

The following settings or destinations must be defined by the system administrator before the MFP can be used to distribute any scanned document(s) on the network.

- Network and E-mail parameters: Defines the parameters for TCP/IP, SMTP, and POP3 protocols to send your scanned document to e-mail addresses.

- Filing destinations: Defines the protocols and destinations to send your scanned document to FTP servers or any personal computers on the network.

---

**Note**

1. If the system administrator has chosen DHCP, then the IP address of TCP/IP, gateway, subnet mask, and DNS server will be automatically given.
  2. When installing the MFP for the first time, it is recommended that the Administrator retain the default system settings. The settings can be customized at a later date, once you are familiar with the operation and functionality.
- 

## Configuration


There are a number of configuration options available which allow you to change the scanner, fax (MB470 MFP & MB480 MFP) and printer settings to suit your own needs. There are three methods of configuring your MFP:

1. From the MFP's web page.
2. From the MFP's Setup Tool utility.
3. From the MFP control panel.

For illustration purposes only, the configuration options shown are as accessed via the control panel.

## . . . from the web page

Type the IP address of the MFP in the URL field of your browser and then press Enter. The MFP web page displays. For example: `http://10.18.207.81`



The screenshot shows the OKI MB480 web interface. The page is titled "OKI PRINTING SOLUTIONS" and "MB480". It features a navigation menu on the left with options for "View Information", "Status", "Supplies Life", "Network", and "System". The main content area is divided into several sections:

- Information:** A table listing device details such as Device Name (OKI-MB480-3B3D18), IPv4 Address (10.18.207.81), MAC Address (00:00:07:0B:0D:10), Location, Serial Number, Asset Number, and Contact Name (Administrator).
- Version Information:** A table listing software versions including CU Version (00.49), PU Version (00.06.09), NIC Program Version (00.17), Web Remote (00.15), and Web Language (00.15).
- Printer Status:** Displays "Toner Remains" at 90% and "Drum Life Remains" at 46%.
- Print Service:** A table showing the status of various services: LPR (Enabled), Port9100 (Enabled), FTP (Disabled), IPP (Disabled), EtherTalk (Enabled), and NetBEUI (Disabled).
- Setting Service:** A table showing the status of various settings: SNMP (Enabled), WEB (Enabled), Telnet (Disabled), and NetBEUI (Disabled).

At the bottom of the page, there is a copyright notice: "Copyright (c) 2009 OKI Data Corporation. All rights reserved."

---


### Note

The Administrative Settings are blocked by a password. Refer to "Pre-configuration information" on page 40.

---

## . . . from the setup tool

If you have not already done so, install the setup tool as described in “MFP Setup Tool: Windows Only” on page 25.




---

### Note

The Administrative Settings are blocked by a password. Refer to “Pre-configuration information” on page 40.

---

. . . from the control panel



1. Press the Down arrow key (1) on the control panel until Menu is highlighted, then press Enter (2).
2. Press the Down arrow key (1) until Admin Setup is highlighted, then press Enter (2).

---

**Note**

The Admin Setup option is blocked by a password. Refer to "Pre-configuration information" on page 40.

---

# The Printer Menu

## Copy function

This is the default mode on Power up, with Access Control disabled. Use the Down arrow key to select other functions and Enter to select an option.

Default option (if relevant) is highlighted.

LEVEL 2	DESCRIPTION	OPTIONS
Copies:	Number of copies required (default 1)	<b>1</b> to 99
<b>100%</b>	Reduce/Enlarge copy	A4->A5 Leg14->Let Leg13.5->Let Leg13->Let A4->B5 Fit to page <b>100%</b> B5->A4 Let->Leg13 Let->Leg13.5 Let->Leg14 A5->A4 Custom
Letter	Paper Supply	Legal13, Legal13.5, Legal14, <b>Letter</b> , A4, A5, B5
Mixed	Mode (Resolution)	<b>Mixed</b> , Photo, HiRes.Mixed, HiRes.Photo
Density: <b>0</b>	Density of print	-3 ~ <b>0</b> ~ +3
<b>Tray1</b>	Input Tray:Selects cassette Tray or Manual feeder (MB460 MFP), or Multi Purpose Tray (MB470 MFP & MB480 MFP)	<b>Tray 1</b> , Tray2, Manual Feeder, MP Tray
<b>Off</b>	Collate:Sets collate function on or off	On, <b>Off</b>
<b>Off</b>	Duplex	On, <b>Off</b>
<b>1in1</b>	N-up:Selects how many prints per page	<b>1in1</b> , 2in1, 4in1(Hor.), 4in1(Ver.)
E.E:	Edge Erase: This sets the peripheral areas of the document to block out.	<b>0.00</b> , 0.25, 0.50, 0.75, 1.00 inch <b>0</b> , 6, 13, 19, 25mm
M.S-R:	Margin Shift - Right: This sets the amount to shift the document image to the right.	<b>0.00</b> , 0.25, 0.50, 0.75, 1.00 inch <b>0</b> , 6, 13, 19, 25mm
M.S-B:	Margin Shift - Bottom: This sets the amount to shift the document down.	<b>0.00</b> , 0.25, 0.50, 0.75, 1.00 inch <b>0</b> , 6, 13, 19, 25mm
	ID Card Copy	On, <b>Off</b>

## Scan/scan to function

Use the **Down** arrow key to select this function and **Enter** to select an option.

### E-mail

LEVEL 2	DESCRIPTION	OPTIONS	
Check Address	Displays the default address (set by the administrator).		
Reply to:	Choose Email "Reply to"	Address Book: Screen Entry: Number: LDAP:	Name Address: Method: OR/AND Search: Address List
Destination	Choose Address from:	Address Book: Screen Entry: Number: LDAP:	Name Address: Method: OR/AND Search: Address List
Subject	Choose from the default subject list (set by the administrator) or enter a subject.	Subject List Screen Entry	
File Name	A file name should be entered for the scanned images. This file name can be entered in Key Pad Mode. Up to 64 characters can be entered as text, except for the following; \\ / : * ? " < >	N/A	
Density	Select density.	-3, -2, -1, <b>0</b> , 1, 2, 3	
Document Size	Select document size.	A4, <b>Letter</b> , Legal13, Legal13.5, Legal14	
File Format	Select file format.	PDF, TIFF	

## Network PC

### Note

The MFP must be connected to a Network server to enable Scan to Network PC to be set up.

Profiles can be created and managed using the machine's web page or the MFP Setup Tool.

LEVEL 2	DESCRIPTION	OPTIONS
Profile	If any profiles have been created the list will be displayed. Max 20 profiles can be created.	
Color Select	Select Color	Color, <b>B/W</b>

## PC

LEVEL 2	DESCRIPTION	OPTIONS
Email	Scan to Email and save file	
Folder	Scan to PC based folder	
Application	Scan to Application1	
Fax (MB470 MFP & MB480 MFP)	Scan to Facsimile and save file	

## Fax function (MB470 MFP & MB480 MFP)

LEVEL 2	DESCRIPTION	OPTIONS
Check Dest.	Displays the selected destination fax number.	
Fax No.	Input a destination fax number.	
Phone Book	Select fax number from the phone book.	
Mode	Select the transmission resolution	<b>Standard</b> Fine Extra Fine Photo
Density	Select density by entering a number in the range -3 to +3	-3 ~ <b>0</b> ~ +3
Document Size	Select document size	A4 <b>Letter</b> , Legal13, Legal13.5, Legal14
Delayed Time	Select transmission time	dd/mm/yyyy hh:mm

## Menu Function

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>View Information</b>	Supplies Life	Toner (n.nk)	Remaining toner	nnn%
		Drum	Remaining	nnn%
	Network	IPv4 Address	Self explanatory	xxx.xxx.xxx.xxx
		Subnet Mask	Self explanatory	xxx.xxx.xxx.xxx
		Gateway Address	Self explanatory	xxx.xxx.xxx.xxx
		MAC Address	Self explanatory	xx.xx.xx.xx.xx.xx
		NIC Program Version	Self explanatory	xx.xx
		NIC Default Version	Self explanatory	xx.xx
		System	Serial Number	Self explanatory
	Asset Number		Self explanatory	XXXXXXXX
	Lot Number		Self explanatory	XXXXXXXXXXXXXXXXXXXXX XXXXXX
	CU Version		Self explanatory	xx.xx
	PU Version		Self explanatory	xx.xx.xx
	Scanner Version		Self explanatory	x.xx.xx
	Fax Version (MB470 MFP & MB480 MFP)		Self explanatory	x.xx
	Total Memory		xx MB	
	Flash Memory		xx MB[Fxx]	

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Print Information</b>	Configuration	Execute	Prints out a report of the machine's configuration	
	Network Information	Execute	Prints out a report of the Network configuration	
	File List	Execute		
	PCL Font List	Execute		
	PS Font List (MB470 MFP & MB480 MFP)	Execute		
	IBM PPR Font List	Execute		
	EPSON FX Font List	Execute		
	Error Log	Execute		
	Demo Page	DEMO1	Execute	Prints a Demonstration page
	MFP Usage Report	Execute	Copies ( <b>1</b> to 99)	Prints a full report of the machine usage
	Supplies Status Report	Execute	Prints a report of the status of all consumables	
	Fax Activity Report (MB470 MFP & MB480 MFP)	Execute		
	Fax Protocol Dump (MB470 MFP & MB480 MFP)	Execute		
	Print System Status	Execute		

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Admin Setup</b>	System Setup		Access Control	Enable/ <b>Disable</b>
			Power Save Time	1/ <b>5</b> /15/30/60/120 minutes
			Return to Stand-by Time	20/40/ <b>60</b> /120/180 seconds
			Default Mode	<b>Copy</b> /Scan/Fax
			Unit of Measure	<b>inch</b> /mm
			Date Format	<b>mm/dd/yyyy</b> , dd/mm/yyyy, yyyy/mm/dd
			Report Full Print	On/ <b>Off</b>
			Panel Contrast	-10~ <b>0</b> ~+10
			Near Life Status	<b>Enable</b> /Disable
	Network Menu	Network Setup	TCP/IP	<b>Enable</b> /Disable
			IP Version	<b>IPv4</b> , IPv4 + IPv6, IPv6
			NetBEUI	<b>Enable</b> /Disable
			NetBIOS over TCP	<b>Enable</b> /Disable
			Ether Talk	<b>Enable</b> /Disable
			IP Address Set	<b>Auto</b> /Manual
			IPv4 Address	xxx.xxx.xxx.xxx
			Subnet Mask	xxx.xxx.xxx.xxx
			Gateway Address	xxx.xxx.xxx.xxx
			DNS Server Primary	xxx.xxx.xxx.xxx
			DNS Server Secondary	xxx.xxx.xxx.xxx
			WINS Server Primary	xxx.xxx.xxx.xxx
			WINS Server Secondary	xxx.xxx.xxx.xxx
			Web	<b>Enable</b> /Disable
Telnet	<b>Enable</b> /Disable			
FTP	<b>Enable</b> /Disable			

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Admin Setup cont.</b>	Network Menu cont.	Network Setup cont.	SNMP	<b>Enable</b> /Disable
			Network Scale	Normal/Small
			Hub Link Setting	<b>Auto Negotiate</b> / 100Base-TX Full/ 100Base-TX Half/ 10Base-T Full/ 10Base-T Half
			Factory Defaults	Execute
	Mail Server Setup		SMTP Server	user defined
			SMTP Port	<b>25</b>
			SMTP Encryption	None/SMTPS/STARTTLS
			POP3 Server	user defined
			POP3 Port	<b>110</b>
			POP Encryption	None/POP3S/STARTTLS
			Authentication Method	<b>None</b> /SMTP/POP
			SMTP User ID	user defined
			SMTP Password	user defined
			POP User ID	user defined
			POP Password	user defined
	LDAP Server Setup		Server Settings	LDAP Server: User defined
				Port Number: 389
				Timeout: 10~ <b>30</b> ~120
				Max. Entries: 2~ <b>100</b>
				Search Root: User defined
			Attributes	Name1: cn
				Name2: sn
				Name3: givenName
				Mail Address: Mail
				Additional Filter: User defined
	Authentication	Method: <b>Anonymous</b> / Simple/Digest-MD5/ Secure Protocol		
	Encryption	<b>None</b> /LDAPS/ STARTTLS		
Secure PrtcSrv Setting	Domain			

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Admin Setup cont.</b>	Printer Setup	Copies	<b>1</b> - 999	
		Duplex	On/ <b>Off</b>	
	Printer Setup cont.	Media Check	<b>Enable</b> /Disable	
		X Dimension	86~ <b>210</b> ~216 millimeter	
		Y Dimension	140~279~297~356 millimeter	
		Resolution	600 dpi/600x1200 dpi/600x2400 dpi/1200x1200 dpi (MB470 MFP & MB480 MFP)	
		Toner Save Mode	<b>Enable</b> /Disable	
		Default Orientation	<b>Potrait</b> /Landscape	
		Form Length	5~ <b>60</b> ~64~128 lines	
		Edit Size	CassetteSize/ <b>Letter</b> /Executive/Statement/Legal14/Legal 13.5/Legal13/A4/A5/A6/B5/ Custom/Com-9 Envelope/Com-10 Envelope/Monarch Envelope/DL Envelope/C5 Envelope/C6 Envelope	
	Scanner Setup	Email Setup	Add "To" Address	<b>On</b> /Off
			Default File Name	User defined
			Subject List	#00, #01m, #02 #03, #04
			Default From	User defined
			Separation Limit	1/3/5/10/30 megabytes/ <b>No limit</b>
			Auto Trans. Report	On/ <b>Off</b>

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Admin Setup Cont.</b>	Fax Setup (MB470 MFP & MB480 MFP)	Clock Adjustment	dd/mm/yyyy hh:mm	Use Up & Down arrow keys to set and Right arrow key to advance.
		Basic Setup	Service Bit	On/ <b>Off</b>
			Country Code	Select the country in which the MFP is located.
			Local Phone No.	<enter>
			Sender ID	<enter>
			MCF(Single Location)	On/ <b>Off</b>
			MCF(Multi Location)	On/ <b>Off</b>
			Error MCF	On/ <b>Off</b>
			Image in MCF	On/ <b>Off</b>
			H/Modem Rate	33.6 Kbps 28.8 Kbps 14.4 Kbps 9.6 Kbps 4.8 Kbps
			TAD Mode	Type1/Type2/ <b>Type3</b>
			Tel Priority Mode	On/ <b>Off</b>
			Fax Setup (MB470 MFP & MB480 MFP) cont.	Basic Setup cont.
	T/F Timer Prg.	<b>20seconds</b> , 35seconds		
	Remote Receive No.	<b>Off</b> , 000, 111, 222, 333, 444, 555, 666, 777, 888, 999, <b>***</b> , ###		
	Ring Response	<b>1 ring</b> / 5/10/15/20 seconds		
	Speaker Volume	Off/Low/ <b>Middle</b> /High		
	Soft Ringer Volume	Off/Low/Middle/ <b>High</b>		
	DRD Type	Type1/ Type2/ Type3/ Type4		
	Fax Line Setup	Redial Tries		0 ~ 10 tries
		Redial Interval		1 ~ 6 minutes
		Dial Tone Detection		On/ <b>Off</b>
		Busy Tone Detection		<b>On</b> /Off
MF(Tone)/DP(Pulse)		DP/ <b>MF</b>		

LEVEL 2	ITEM	DESCRIPTION/OPTIONS	
<b>Admin Setup Cont.</b>	PCL Setup	Font Source	Resident/Resident2/ Downloaded
		Font Number	I0/C1/S1
		Font Pitch	0.44 ~ <b>10.00</b> ~ 99.99 CPI
		Symbol Set	Available sets
		A4 Print Width	78/ <b>80</b> column
		White Page Skip	On/ <b>Off</b>
		CR Function	<b>CR</b> /CR + LF
		LF Function	<b>LF</b> /LF + CR
		Print Margin	<b>Normal</b> /1/5 inch/1/6 inch
		Pen Width Adjust	<b>On</b> /Off
		Tray ID#: PCL MNID	1 ~ <b>2</b> ~ 59
		PCL T0ID	1 ~ <b>4</b> ~ 59
		PCL T1ID	<b>1</b> ~ 59
	IBM PPR Setup	Character Pitch	<b>10</b> /12/17/20 CPI/ Proportional
		Font Condense	12CPI to 20CPI 12CPI to 12CPI
		Character Set	<b>SET-2</b> /SET-1
		Symbol Set	Available Sets
		Letter O Style	Enable/ <b>Disable</b>
		Zero Character	<b>Normal</b> /Slashed
	IBM PPR Setup cont.	Line Pitch	<b>6 LPI</b> / 8 LPI
		White Page Skip	On/ <b>Off</b>
		CR Function	<b>CR</b> /CR + LF
		LF Function	<b>LF</b> /LF + CR
		Line Length	<b>80</b> /136 column
		Form Length	<b>11</b> /11.7/12 inch
		TOF Position	<b>0.0</b> ~ 0.1 ~ 1.0 inch
		Left Margin	<b>0.0</b> ~ 0.1 ~ 1.0 inch
		Fit to Letter	<b>Enable</b> /Disable
		Text Height	<b>Same</b> /Diff

LEVEL 2	ITEM	DESCRIPTION/OPTIONS		
<b>Admin Setup Cont.</b>	EPSON FX Setup	Character Pitch	<b>10/12/17/20</b> CPI/ Proportional	
		Character Set	<b>SET-2</b> /SET-1	
		Symbol Set	Available sets	
		Letter O Style	Enable/ <b>Disable</b>	
		Zero Character	<b>Normal</b> /Slashed	
		Line Pitch	<b>6 LPI</b> /8 LPI	
		White Page Skip	On/ <b>Off</b>	
		CR Function	<b>CR</b> /CR + LF	
		Line Length	<b>80</b> /136 column	
		Form Length	<b>11</b> /11.7/12 inch	
		TOF Position	<b>0.0</b> ~ 0.1 ~ 1.0 inch	
		Left Margin	<b>0.0</b> ~ 0.1 ~ 1.0 inch	
		Fit to Letter	<b>Enable</b> /Disable	
		Text Height	<b>Same</b> /Diff	
	PS Setup (MB470 MFP & MB480 MFP)	L1 Tray	TYPE1/TYPE2	
		Parallel Protocol	ASCII/RAW	
		USB Protocol	ASCII/RAW	
		Network Protocol	ASCII/RAW	
	Memory Setup	Receive buffer size	<b>Auto</b> /0.1/0.2/0.5/1/2/4 MB	
		Resource Save (MB470 MFP & MB480 MFP)	Auto/Off/0.1/0.2/0.5/1/2/4 MB	
	Change Password	Select "New password" and enter		
		Verify Password		
	Settings	Save Settings	Execute	
		Reset Settings	Execute	

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Printer Menu</b>	Tray Configuration	Manual feed (MB460 MFP)	<b>On/Off</b>	
		Paper Feed	<b>Tray1</b> /Tray2/MP Tray	
		Auto Tray Switch	<b>On/Off</b>	
		Tray Sequence	<b>Down/Up</b> /Paper Feed Tray	
		MP Tray Usage (MB470 MFP & MB480 MFP)	When Mismatching/Do not use	
		Tray1 Config	Paper Size	A4/A5/B5/Legal14/Legal13.5/Legal13/ <b>Letter</b> /Executive/Statement/Custom
			Media Type	<b>Plain</b> /Letterhead/Bond/Recycled/Cardstock/Rough
			Media Weight	Light/Medium Light/Medium/ Medium Heavy/ Heavy
		Tray2 Config	Paper Size	A4/A5/B5/Legal14/Legal13.5/Legal13/ <b>Letter</b> /Executive/Custom
			Media Type	<b>Plain</b> /Letterhead/Bond/Recycled/Cardstock/Rough
			Media Weight	Light/Medium Light/Medium/ Medium Heavy/ Heavy
		MP Tray Config (MB470 MFP & MB480 MFP)	Paper Size	A4/A5/A6/B5/Legal14/Legal 13.5/Legal13/ <b>Letter</b> / Executive/Statement/Custom/Com-9 Envelope/Com-10 Envelope/Monarch Envelope/DL Envelope/C5 Envelope/C6
			Media Type	<b>Plain</b> /Letterhead/Transparency/Labels/Bond/Recycled/Card Stock/Rough
			Media Weight	Light/Medium Light/ <b>Medium</b> / Medium Heavy/ Heavy

LEVEL 2	ITEM		DESCRIPTION/OPTIONS		
<b>Printer Menu Cont.</b>	Tray Configuration cont.	Manual Feeder Config (MB460 MFP)	Paper Size	A4/A5/A6/B5/Legal14/Legal13.5/Legal13/ <b>Letter</b> /Executive/Statement/Custom/Com-9 Envelope/Com-10 Envelope/Monarch Envelope/DL Envelope/C5 Envelope/C6 Envelope	
			Media Type	<b>Plain</b> /Letterhead/Transparency/Labels/Bond/Recycled/Card Stock/Rough	
		Manual Feeder Config (MB460 MFP) cont.	Media Weight	Light/Medium Light/ <b>Medium</b> / Medium Heavy/ Heavy	
	Printer Adjust	Manual Timeout	Off/30/ <b>60</b> /120/180/240/300 secs.		
		Low Toner	<b>Continue</b> /Stop		
		Jam Recovery	<b>On</b> /Off		
		Error Report	On/ <b>Off</b>		
		Start Up	On/ <b>Off</b>		
		Paper Black Setting	-2 ~ <b>0</b> ~ +2		
		Auto Continue	On/ <b>Off</b>		
		Timeout in Job	Off/5/10/20/30/ <b>40</b> /50/60/90/120/150/180/210/240/270/300 seconds		
		Timeout Local	0/ <b>5</b> ~40~290/295/300 seconds		
		Timeout Net	0/5~ <b>90</b> ~290/295/300 seconds		
		Personality	Auto/PCL/IBM PPR/EPSON FX/ PS3 EMULATION(MB470 MFP & MB480 MFP)		
		Hex Dump	Execute		
		Darkness	-2 ~ <b>0</b> ~ +2		
		Cleaning	Execute		
		X Adjust	-2.00 ~ <b>0.00</b> ~ +2.00 millimeter		
		Y Adjust	-2.00 ~ <b>0.00</b> ~ +2.00 millimeter		
		Duplex X Adjust	-2.00 ~ <b>0.00</b> ~ +2.00 millimeter		
Duplex Y Adjust	-2.00 ~ <b>0.00</b> ~ +2.00 millimeter				
Place Page	<b>Center</b> /Left				

LEVEL 2	ITEM		DESCRIPTION/OPTIONS	
<b>Copy Menu</b>	Job Build Scanning		On/ <b>Off</b>	
	Copies		<b>1</b> -99	
	Reduce/Enlarge		A4>A5 / Leg14>Let / Leg13.5>Let / Leg13>Let / A4>B5 / Fit to Page / <b>100%</b> / B5>A4 / Let>Leg13 / Let>Leg13.5 / Let>Leg14 / A5>A4	
	Mode		<b>Mixed</b> / Photo / HiRes.Mixed / HiRes.Photo	
	Density		-3/-2/-1/ <b>0</b> /+1/+2/+3	
	Input Tray		<b>Tray1</b> /Tray2/Manual Feeder (MB460 MFP)/MP Tray(MB470 MFP & MB480 MFP)	
	Collate		On/ <b>Off</b>	
	Duplex		On/ <b>Off</b>	
	N-up		<b>1in1</b> /2in1/4in1(Hor.)/4in1(Ver.)	
	Edge Erase		<b>0.00</b> /0.25/0.50/0.75/1.00 inch <b>0</b> /6/13/19/25mm	
	Margin Shift Right		<b>0.00</b> /0.25/0.50/0.75/1.00 inch <b>0</b> /6/13/19/25mm	
	Margin Shift Bottom		<b>0.00</b> /0.25/0.50/0.75/1.00 inch <b>0</b> /6/13/19/25mm	
<b>Scanner Menu</b>	Scan to Email	Job Build Scanning	On/ <b>Off</b>	
		Density	-3/-2/-1/ <b>0</b> /+1/+2/+3	
		Document size	A4/ <b>Letter</b> /Legal13/Legal13.5/Legal14	
		Color Select	Color/ <b>B/W</b>	
		Color Format	File Format	<b>PDF</b> /TIFF/JPEG
			Compression Rate	<b>Low</b> /Medium/High
		Color Format cont.	Resolution	100/ <b>150</b> /200/300 dpi
		B/W Format	Grayscale	On/ <b>Off</b>
			File Format	<b>PDF</b> /TIFF
			Compression Rate	G3/ <b>G4</b> /Raw
	Resolution		100/150/ <b>200</b> /300/ 400/600 dpi	
	Address Book	Email Address	<b>#00</b> to #99	
		Group Address	<b>G00</b> to G19	
	Scan to Network PC	Color Select	Color/ <b>B/W</b>	

LEVEL 2	ITEM	DESCRIPTION/OPTIONS	
Fax Menu (MB470 MFP & MB480 MFP)	Auto Receive	Fax Manual Tel/Fax TAD DRD	
	Mode	<b>Standard</b> /Fine/Extra Fine/Photo	
	Density	-3/-2/-1/ <b>0</b> /+1/+2/+3	
	Document Size	A4/ <b>Letter</b> /Legal13/Legal13.5/Legal14	
	Phone Book	Speed Dial/One touch dial	#00 to #99
Group Dial		G00 to G09	
<b>System Shutdown</b>	Shutdown Start	Execute	

# Setting the fax facility (MB470 MFP & MB480 MFP)

## Initial set up

The following parameters must be set before using the fax function on your MFP:

- Date and time
- Country code
- Local Phone No.
- Sender ID

There are other parameters that can be adjusted to suit your personal preferences later if required, refer to fax set up table for details (See "Advanced set up" on page 65.).

To set fax parameters:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Press Enter to select the Clock Adjustment menu.
6. Using the arrow keys and keypad, enter the time and date.

---

### Note

Use the Right and Left arrow keys to move between digits.

---

7. Press Enter to confirm.
8. Using the Down arrow key, scroll to Basic Setup and press Enter.
9. Using the Down arrow key, scroll to Country Code and press Enter.
10. Using the arrow keys, scroll to the country in which the MFP is situated and press Enter to confirm.
11. Using the Down arrow key, scroll to Local Phone No. and press Enter
12. Using the keypad or arrow keys, type in the local phone number press Enter to confirm.
13. Using the Down arrow key, scroll to Sender ID and press Enter.
14. Using the keypad or arrow keys and the on-screen keypad, type in the sender ID.
15. Highlight Done and press Enter.

**16.** Press the Left arrow key to exit the menu.

---

**Note**

If required, set the dialling method for your region (Pulse or Tone).

If connecting the machine through a private branch exchange (PBX) line, you must also specify a dial prefix to allow the machine to obtain an external line before dialling. Refer to "Connecting to a PBX" on page 67.

---

## Advanced set up

Your machine offers a multitude of features which reduce the time required for manual operation and make fax communications more efficient.

### Adding a speed dial entry to the phone book

The machine can hold up to 100 speed dial numbers in the phone book. To assign a speed dial number to the phone book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Fax Menu and press Enter.
3. Using the Down arrow key, scroll to Phone Book and press Enter.
4. Press Enter to select Speed Dial/One Touch Dial.
5. Using the arrow keys, scroll to the required speed dial entry position and press Enter.
6. Press Enter to select Fax.No.
7. Using the keypad, type in the destination fax number and press Enter.

---

**Note**

If the destination fax number has an "extension number", press the "\$" button three times to insert a pause (-) between numbers. The machine will enter a pause when dialling. See "Character switching" on page

The maximum length of a number is 32 digits.

---

8. Press Enter to select Name.
9. Using the keypad or arrow keys and the onscreen keypad, type in the name.

---

**Note**

The maximum length of a name is 16 characters.

---

10. Highlight Done and press Enter.
11. Using the Down arrow key, scroll to Done and press Enter to confirm and add your entry to the phone book.

**12.** Press the Left arrow key to exit the menu.

### **Adding a group entry to the phone book**

The machine can hold up to 10 group dial settings.

To add a new group dial number to the phone book:

- 1.** Using the Down arrow key, scroll to Menu and press Enter.
- 2.** Using the Down arrow key, scroll to Fax Menu and press Enter.
- 3.** Using the Down arrow key, scroll to Phone Book and press Enter.
- 4.** Using the Down arrow key, scroll to Group Dial and press Enter.
- 5.** Using the arrow keys, scroll to the required group dial entry position and press Enter.
- 6.** Press Enter to select Speed Dial List.
- 7.** Scroll through the list of speed dial entries and press Enter to mark (\*). When all required entries are selected, press the Left arrow key.
- 8.** Press Enter to select Group Name.
- 9.** Using the keypad or arrows and the on-screen keypad, type in the name.

---

#### **Note**

The maximum length of a name is 16 characters.

---

**10.** Highlight Done and press Enter.

**11.** Using the Down arrow key, scroll to Done and press Enter to confirm and add your entry to the phonebook.

**12.** Press the Left arrow key to exit the menu.

### **Deleting a speed dial entry from the phone book**

To delete a speed dial entry from the phone book:

- 1.** Using the Down arrow key, scroll to Menu and press Enter.
- 2.** Using the Down arrow key, scroll to Fax Menu and press Enter.
- 3.** Using the Down arrow key, scroll to Phone Book and press Enter.
- 4.** Press Enter to select Speed Dial List/One Touch Dial.
- 5.** Using the arrow keys, scroll to the required speed dial and press Enter.
- 6.** Using the Down arrow key, scroll to Clear and press Enter.
- 7.** Using the Up arrow key, scroll to Yes and press Enter.
- 8.** Press the Left arrow key to exit the menu.

## **Deleting a group dial entry from the phone book**

To delete a group dial entry from the phone book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Fax Menu and press Enter.
3. Using the Down arrow key, scroll to Phone Book and press Enter.
4. Using the Down arrow key, scroll to Group Dial and press Enter.
5. Using the arrow keys, scroll to the required group dial and press Enter.
6. Using the Down arrow key, scroll to Clear and press Enter.
7. Using the Up arrow key, scroll to Yes and press Enter.
8. Press the Left arrow key to exit the menu.

## **Connecting to a PBX**

Private Branch Exchanges (PBXs) are private telephone systems used to route calls internally, for example, in a company. When dialling a telephone number, if a prefix is required to open an outside line, the line is connected to a PBX. If this MFP is going to be connected to a PBX, press the # key three times to insert a "-", then type in the destination fax number. This will ensure the MFP waits until an outside line is available before dialling the rest of the number.

## **Automatic redial**

You can set the fax to automatically redial if the initial fax transmission fails. The machine will redial on:

- Line busy
- No answer
- Communication error

To set auto-redial:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Fax Line Setup and press Enter.
6. Press Enter to select the Redial Tries.
7. Using the arrow keys, select the required number of redial attempts (between 0 and 10), then press Enter to confirm.
8. Using the Down arrow key, scroll to Redial Interval and press Enter.
9. Using the arrow keys, select the required redial interval (between 1 and 6 minutes), then press Enter to confirm.
10. Press the Left arrow key to exit the menu.

## Reception Mode

You can change the way your MFP handles incoming fax transmissions and telephone calls (if you have a telephone handset connected) depending on your office requirements. Choose from:

- Fax
- Manual
- Tel/Fax
- TAD
- DRD

To change the reception mode:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Fax Menu and press Enter.
3. Press Enter to select Auto Receive.
4. Using the arrow keys, select the required reception mode and press Enter.
5. Press the Left arrow key to exit the menu.

## Adding a telephone handset

If you want to add a telephone handset to your MFP, connect the line to the Tel socket (in certain countries it may be necessary to use a telephone plug adaptor).

You will also need to update the telephone settings to set the ring response:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Basic Setup and press Enter.
6. Using the Down arrow key, scroll to Ring Response and press Enter.
7. Using the arrow keys, select the required response setting (between 1 ring and 20 seconds) and press Enter.
8. Press the Left arrow key to exit the menu.

---

### Note

You must also set the reception mode to the appropriate setting. See "Reception Mode" on page 68.

---

### Note

If the telephone handset is in use (off hook), dialling for speech purposes is not available using the MFP keypad or speed dial keys.

---

# Managing the address book

The following section describes how to add/remove/modify e-mail addresses to/from the Address Book.

## Adding an email address entry

The machine can hold up to 100 e-mail addresses in the address book. To assign a new email address to the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Press Enter to select Email Address.
5. Using the arrow keys, scroll to the required email address entry position and press Enter.
6. Press Enter to select Address.
7. Using the keypad or arrows keys and the on-screen keypad, type in the new email address.

---

**Note**

The maximum length of address is 80 characters.

---

8. Highlight Done and press Enter.
9. Press Enter to select Name.
10. Using the keypad or arrows keys and the on-screen keypad, type in the name.

---

**Note**

The maximum length of name is 16 characters.

If you do not enter a name, this column remains blank.

---

11. Highlight Done and press Enter.
12. Using the Down arrow key, scroll to Done and press Enter to confirm and add your entry to the address book.
13. Press the Left arrow key to exit the menu.

## Deleting an email address entry

To delete an email address entry from the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Press Enter to select Email Address.
5. Using the arrow keys, scroll to the required email address and press Enter.
6. Using the Down arrow key, scroll to Clear and press Enter.
7. Using the Up arrow key, scroll to Yes and press Enter.
8. Press the Left arrow key to exit the menu.

## Modifying an email address entry

To edit an email address entry from the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Press Enter to select Email Address.
5. Using the arrow keys, scroll to the required email address and press Enter.
6. If required, press Enter to select Address. Update the details:
7. Using the keypad or arrow keys and on-screen keypad, edit the email address.
8. Highlight Done and press Enter.
9. If required, use the Down arrow key to scroll to Name and press Enter. Update the details:
10. Using the keypad or arrow keys and on-screen keypad, edit the email name.
11. Highlight Done and press Enter.
12. Using the Down arrow key, scroll to Done and press Enter.
13. Press the Left arrow key to exit the menu.

## Adding a group entry

The machine can hold up to 20 group addresses. To add a new group address to the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Using the Down arrow key, scroll to Group Address and press Enter.
5. Using the arrow keys, scroll to the required group address entry position and press Enter.
6. Press Enter to select Address List.
7. Scroll through the list of email address entries and press Enter to mark (\*). When all required entries are selected, press the Left arrow key.
8. Press Enter to select Group Name.
9. Using the keypad or arrows keys and the on-screen keypad, type in the name.

---

### Note

The maximum length of a name is 16 characters.

If you do not enter a Group name, Group name column remains blank.

---

10. Highlight Done and press Enter.
11. Using the Down arrow key, scroll to Done and press Enter to confirm and add your entry to the address book.
12. Press the Left arrow key to exit the menu.

## Deleting a group address entry

To delete a group address entry from the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Using the Down arrow key, scroll to Group Address and press Enter.
5. Using the arrow keys, scroll to the required group address and press Enter.
6. Using the Down arrow key, scroll to Clear and press Enter.
7. Using the Up arrow key, scroll to Yes and press Enter.
8. Press the Left arrow key to exit the menu.

## Modifying a group address entry

To edit a group address entry from the address book:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Scanner Menu and press Enter.
3. Using the Down arrow key, scroll to Address Book and press Enter.
4. Using the Down arrow key, scroll to Group Address and press Enter.
5. Using the arrow keys, scroll to the required group address and press Enter.
6. If required, press Enter to select Address List. Update the details:
  - a. Using the arrow keys, scroll through the list and modify as required. Press Enter to remove any address from the group listing; the "\*" will be removed from the address.
  - b. Press the Left arrow key to exit the list.
7. If required, use the Down arrow key to scroll to Group Name and press Enter. Update the details:
  - a. Using the keypad or arrow keys and on-screen keypad, edit the email name.
  - b. Highlight Done and press Enter.
8. Using the Down arrow key, scroll to Done and press Enter.
9. Press the Left arrow key to exit the menu.

# Access Control

---

The operation and functionality of this machine can be limited to authorized personnel only by the simple introduction of a 4 to 9 digit PIN (Personal Identification Number). This is known as Access Control. The greater the number of digits in the PIN - the more secure it is.

Your MFP supports the following PIN types:

- Administrator PIN; This is the PIN for the system administrator(s).  
If a PIN is registered as an administrator, the Admin password entry screen is displayed, and when an Admin password is entered, it will be authenticated as an administrator.
- User PIN; This is PIN for general users.  
If a PIN is registered as a general user, the function selection screen is displayed, also after PIN entry, the function selection screen is displayed.

After using the machine, you will be expected to log out. Leaving the machine in access control mode will render the machine not usable by unauthorised users.

## Enabling Access Control

Access Control Enable/Disable is switched in Menu > Admin Setup > System Setup > Access Control.

If your administrator has enabled access control on your machine, it will automatically start up in access control mode. You will not be able to use it until you have provided valid login information.

With Access Control set to enable, the display reverts to the System Setup screen immediately following the setting change. If one of the functions such as Print, Fax Send or PC Scan is running, the display will only revert to the System Setup screen when the task has been completed.

## Logging in

1. If the Enter PIN screen is displayed, use the keypad to enter your PIN.
2. Press Enter (or the **Start** button) to confirm.

---

### Note

A valid PIN consists of 4 to 9 digits.

Numbers entered are not displayed on-screen, they are replaced by "\*".

If the PIN entered is invalid, "Incorrect Password" is displayed for 3 seconds and the display reverts to the Enter the PIN screen.

---

3. At the Enter Password screen, use the on-screen keypad to enter your password.
4. Use the Up arrow key to highlight Done and press Enter to confirm.

# Logging out

When you have finished using the machine, make sure you log out:

---

**Note**

With Access Control enabled, Logout options are displayed in the Menu on the Mode Selection screen.

---

1. Using the Down arrow key, highlight Logout and then press Enter.  
The Confirm Logout screen is displayed.
  2. Using the Down arrow key, highlight Yes and then press Enter to confirm.  
The display reverts to the Enter PIN screen.
- 

**Note**

When the MFP control panel is left inactive for a prescribed length of time, the display automatically reverts to the Enter PIN screen if Access Control is enabled.

---

## Operation time-out

When the MFP control panel is left inactive for a prescribed length of time (Operation Time-out), the display automatically reverts to the idle screen if Access Control is disabled.

If an error state occurs, Operation Time-out is disabled.

After Operation Time-out, the display automatically reverts to the Enter PIN screen if Access Control is enabled.

The length of the Operation Time-out depends on the setting in Menu Mode > Admin Setup > System Setup > Return to Standby Time.

# Operation

---

With its intuitive control panel, this Multi Function Product (MFP) is designed to be easy to use.

---

**Note**

If Access Control has been enabled, you will first have to enter your Password/PIN.

---

The following sections describe how to copy, fax (MB470 MFP & MB480 MFP), and scan your documents.

## Loading document(s)

---

**Note**

The fax function is available only for MB470 MFP and MB480 MFP.

---

This MFP can scan/copy/send/fax document(s) either in the ADF (Automatic Document Feeder) or on the glass. If you need to send multiple pages, load your papers in the ADF. The ADF can hold up to 50 pages at one time.

If you need to scan/copy/send/fax pages from books, newspaper clippings, or paper with wrinkles or curls, place them on the glass.

## Placing document(s) in the ADF

Before using the ADF, please make sure that your paper meets the following specifications:

- Document(s) can range in size from 5.8" x 8.2" (148 mm x 210m m) - 8.5" x 14" (216 mm - 356 mm)
- Document(s) can range in weight from 16 to 28 lbs US Bond (60 - 105 g/m<sup>2</sup>) with sheet thickness up to 0.4" (11 mm).
- Document(s) should be square or rectangular and in good condition (not fragile or worn).
- Document(s) should be free of curl, wrinkle, tears, wet ink, or punch holes.
- Document(s) should be free of staples, paper clips, paper sticky notes.


- Keep the glass clean and without any documents left on it.

---

**Note**

- Glossy paper should not be used on the ADF.
- You cannot scan A6 document in the ADF.
- To transmit irregular types of document(s), place the document(s) on the glass or make a copy first and then transmit the copy instead.

- 
1. If you have multiple pages, fan the pages to avoid paper jams. The ADF holds up to 50 pages at one time.



2. Place the document with the text face UP in the ADF and make sure that the top of each page is fed in first.




3. Adjust the Paper Guides (1) to centre the document in the ADF.



## Placing document(s) on the glass

1. Open the document cover.
2. Place your document with the text face DOWN on the glass and align the top of the page to the upper-left corner.



3. Close the document cover.

# Copying

---

## **Note**

Factory default setting is Copy mode.

---

## **Basic operation**

1. Place your document(s) with text face Up in the ADF or face Down on the glass.
  2. Set your copying options as required. For further details refer to the following sections.
  3. Then press the Start button.
- 

## **Note**

When using the ADF, in order to prevent paper jams, if you wish to cancel the copy process, press the Stop button once to stop the process and a second time to eject the paper.

---

## **Advanced operation**

Using the options available, you can alter the copy output to suit your needs:

1. Press Enter button.
2. Select required parameter with Down arrow key and press Enter.
3. Pressing Up and Down arrow keys, select value and press Enter.

Options are (factory default settings in bold text):

MENU ITEM	OPTIONS
Copies	<b>1</b> - 99
Reduce/Enlarge	A4>A5, Leg14>Let, Leg13.5>Let, Leg13>Let, A4>B5, Fit to page, <b>100%</b> , B5>A4, Let>Leg13, Let>Leg13.5, Let>Leg14, A5>A4, Custom
Paper Supply	Legal13, Legal13.5, Legal14, <b>Letter</b> , A4, A5, B5
Mode	<b>Mixed</b> , Photo, HiRes.Mixed, HiRes.Photo
Density	-3, -2, -1, <b>0</b> , +1, +2, +3
Input Tray	<b>Tray1</b> , Tray2(optional), Manual Feeder(MB460 MFP), MP Tray(MB470 MFP & MB480 MFP)
Collate	On, <b>Off</b>
Duplex	On, <b>Off</b>
N-up	<b>1in1</b> , 2in1, 4in1(Hor.), 4in1(Ver.) <sup>a</sup>
Edge_Erase	<b>0.00</b> inch, 0.25 inch, 0.50 inch, 0.75 inch, 1.00 inch or 0 mm, 6 mm, 13 mm, 19 mm, 25 mm <sup>b</sup>
M_SHIFT_R	<b>0.00</b> inch, 0.25 inch, 0.50 inch, 0.75 inch, 1.00 inch or 0 mm, 6 mm, 13 mm, 19 mm, 25 mm <sup>c</sup>
M_SHIFT_B	0.00 inch, 0.25 inch, 0.50 inch, 0.75 inch, 1.00 inch or 0 mm, 6 mm, 13 mm, 19 mm, 25 mm <sup>d</sup>
Id Card Copy	On, <b>Off</b>

- a. N-up can only be changed from 1in1 if paper size is set to A4 or Letter and documents are scanned from the ADF. Collate always defaults to "Off". Reduce/Enlarge to "100%". Reduce/enlarge to "100%," Edge erase to "0mm (0.00in)" and Margin shift -Right/Bottom to "0mm (0.00in)".
- b. The setting displayed, mm or inch, depends on the setting in Admin Setup - System Setup - Unit of Measure in Menu Mode. If Edge Erase is set to other than "0 mm" or "0.00 in," Reduce/Enlarge always defaults to "100%", N-up to "1in1", and Margin Shift - Right/Bottom to "0 mm (0.00 in)".
- c. Any parts of the image that do not fit on the paper as a result of this setting, are not printed. The setting displayed mm or inch, depends on the setting in Admin Setup - System Setup - Unit of Measure in Menu Mode. If Edge Erase is set to other than "0 mm" or "0.00 in," Reduce/Enlarge always defaults to "100%", N-up to "1in1", and Margin Shift - Right/Bottom to "0 mm (0.00 in)".
- d. Any parts of the image that do not fit on the paper as a result of this setting, are not printed. The setting displayed mm or inch, depends on the setting in Admin Setup - System Setup - Unit of Measure in Menu Mode. If Edge Erase is set to other than "0 mm" or "0.00 in," Reduce/Enlarge always defaults to "100%", N-up to "1in1", and Margin Shift - Right/Bottom to "0 mm (0.00 in)".

**4.** Press the Left arrow key to return to the start menu.

# Scanning

## Basic Operation

1. Place your document(s) with the text face up in the ADF or face Down on the glass.
2. Select Scan mode using the Down arrow button on the control panel.
3. Press Enter.
4. Press the Down arrow key and select the scan destination from the following options:
  - Email
  - Network PC
  - PC
5. Set your scanning options as required. For further details refer to the following sections.
6. Then press the Start button.

---

### Note

When using the ADF, in order to prevent paper jams, if you wish to cancel the copy process, press the Stop/Cancel button once to stop the process and a second time to eject the paper.

---

## Scan To Email

1. Place your document(s) with text face Up in the ADF or face Down on the glass.
2. Using the Down arrow key, scroll to Scan and press Enter.
3. Press Enter to select Email.
4. Using the Up arrow key, scroll to Reply To and press Enter.
5. Set the reply address from either:
  - Address Book - select from the address book entries
  - Screen Entry - enter directly using the keypad
  - Number - enter an address or group address number
  - LDAP - select from a Lightweight Directory Access Protocol (LDAP) server
6. If prompted, select More and change address, otherwise select Done.
7. Using the Down arrow key, scroll to Destination and press Enter.

- 8.** Set the destination address(s) from either:
- Address Book - select from the address book entries
  - Screen Entry - enter directly using the keypad
  - Number - enter an address or group address number
  - LDAP - select from a Lightweight Directory Access Protocol (LDAP) server
- If prompted, select More and add additional addresses, otherwise select Done.
- 9.** Using the Down arrow key, scroll to Subject and press Enter.
- 10.** Set the subject from either:
- Subject List
  - Screen Entry
- 11.** Using the Down arrow key, scroll to File Name and press Enter.
- 12.** Using the keypad or arrow keys and the on-screen keypad, type in the file name.
- 13.** Highlight Done and press Enter.
- 14.** If required, adjust the density setting:
- a. Using the Down arrow key, scroll to Density and press Enter.
  - b. Highlight the required setting and press Enter.
- 15.** If required, adjust the document size:
- a. Using the Down arrow key, scroll to \*A4 and press Enter.
  - b. Highlight the required setting and press Enter.
- 16.** If required, adjust the file format:
- If you are sending a color file;
    - (i) Using the Down arrow key, scroll to Color Select (Color) and press Enter.
    - (ii) Highlight the required setting and press Enter.
  - If you are sending a black and white file;
    - (i) Using the Down arrow key, scroll to Color Select (B/W) and press Enter.
    - (ii) Highlight the required setting and press Enter.

## Scan to Network PC

Before sending your document to a file server, profiles should be setup first to speed up the process. A profile contains a list of filing parameters such as your filing protocol, directory, file name and other scanning parameters. Add a new profile by either entering the machine's web page or installing and starting the Network Setup Tool on the CD-ROM supplied.

---

### Note

You can create up to 20 profiles.

---

1. Place your document(s) with text face Up in the ADF or face Down on the glass.
2. Using the Down arrow key, scroll to Scan and press Enter.
3. Using the Down arrow key, scroll to Network PC and press Enter.
4. The file server profile list is displayed. If no profiles exist, the profile list is blank.
5. Using the arrow keys, scroll to the required profile (filing destination) and press Enter.
6. Press the Start button.

## Scan to PC

---

### Note

Ensure that the Actkey Utility is installed and set up first. Refer to "Actkey Utility: Windows Only, USB Only" on page 25.

---


The scanner function can be controlled from either the MFP (Push Scan) or from the PC (Pull Scan).

### Push Scan

1. Place your document(s) with text face Up in the ADF or face Down on the glass.
2. Using the Down arrow key, scroll to Scan and press Enter.
3. Using the Down arrow key, scroll to PC and press Enter.
4. The Push Scan screen displays four options. Using the arrow keys, scroll to the required function and press Enter:
  - a. Email

When the Email function is selected, the ActKey Utility executes PC scan in accordance with your settings for "Scan to Email". The scanned image data

is saved in the specified folder and is ready for the software to send as an attachment. Complete the data on screen and send.



b. Folder

When the Folder function is selected the Actkey Utility executes PC scan in accordance with your settings for "Scan to Folder". The scanned image data is saved in the specified folder.

c. Application

When the Application function is selected the Actkey Utility executes PC scan in accordance with your settings for "Scan to Application1". The scanned image data is saved in the application specified by the Actkey Utility.

d. Fax (MB470 MFP & MB480 MFP)

When the Fax function is selected, the Actkey Utility executes PC scan in accordance with your settings for Scan to PCFax. The scanned image data is saved in the specified folder and is ready for the software to send as an attachment. Complete the data on screen and send.

**5.** Press the Start button.

## Pull Scan

Double click the Actkey Icon on your desktop. The Actkey console (below) will display.



The functions below, can now be controlled from the PC:

- Scan to Application1
- Scan to Application2
- Scan to Email
- Scan to Folder
- Scan to Fax (MB470 MFP & MB480 MFP)

Scan to "Application2" works exactly the same as scan to Application1, simply allowing an alternative application to be selected.

As the cursor passes over an icon, the parameters set for that icon appear in a text box, a single click will select that option.

# Faxing (MB470 MFP & MB480 MFP): Basic operation

## Searching the phone book

To search the contents of the phone book, you can either:

- Use the arrow keys to scroll through the list and highlight the required entry.

---

### Note

Lists of Speed Dials and Group Dials that have been added to the Phone Book are displayed in the order Group Dial (G00~ G09) and Speed Dial/One Touch Dial (#00~#99).

---

- Using the keypad to type in a search character, for example the first letters of the name. Destinations whose initial character matches the entered character appears on the screen.

---

### Note

You can switch between numbers, upper-case/lower-case letters, and symbols by pressing the same key multiple times. When pressing multiple times, you must re-press the key within 2 seconds of the previous press.

Refer to Character switching see "Character Switching" on page 16.

---

## Sending a Fax

1. Place your document(s) with text face Up in the ADF or face Down on the glass.
2. Using the Down arrow key, scroll to Fax and press Enter.
3. Enter the destination fax number by either:
  - a. Selecting Fax No. and typing in the number using the numeric keypad.

---

### Note

You can type in a destination number in full or type in a speed dial or group dial number:

To enter a speed dial; press the “#” key and then enter the two-digit speed dial number, for example “#29”.

To enter a group dial; press the “\*” key and then enter the one-digit group dial number, for example “\*3”.

Fax number and ID registered in the selected dial number are displayed.

---

- (i) Press Enter.
    - (ii) At the continue prompt, select More to add additional numbers or Done to confirm.
  - b. Selecting Phone Book and selecting the number from the phone book entries.
    - (i) Search the phone book entries, refer to “Searching the phone book” on page 85.
    - (ii) Repeat until all required entries are selected.
    - (iii) Press the Left arrow key to exit the list.
4. If required, press the Up arrow key and scroll to Check Dest. to view /edit the list of fax numbers:
  - Press Enter to remove any entry from the list (no longer displays \* next to the entry).
  - Press the Left arrow key to exit the list.
5. Press the Start button to send your document(s).

---

### Note

If you wish to cancel faxing, press Stop to abort the operation.

Fax transmissions are sent in black and white only.

---

# Faxing (MB470 MFP & MB480 MFP): Advanced operation

## Changing the Fax Quality (Mode)

The machine is preset to "Standard". If required, you can select Fine, ExtraFine, or Photo to improve fax quality.

To change fax quality:

1. Follow "Sending a Fax" process steps 1 to 4.
2. Using the Down arrow key, scroll to Standard and press Enter.
3. Using the Down arrow key, scroll to the required quality setting and press Enter.
4. Press the Start button to send your document(s).

---

### Note

After you have completed your fax operation, the machine will automatically return to the preset value.

---

## Adjusting Density

The machine is preset to the "Normal" level of Density. If your original document comes with a lighter or darker contrast, you can improve the quality by adjusting the density setting.

To change density:

1. Follow "Sending a Fax" process steps 1 to 4.
2. Using the Down arrow key, scroll to Density:0 and press Enter.
3. Using the Down arrow key, scroll to the required density setting and press Enter.
4. Press the Start button to send your document(s).

---

### Note

After you have completed your fax operation, the machine will automatically return to the preset value.

---

## Document Size

The machine is preset to "Letter" size.

To change the document size:

1. Follow "Sending a Fax" process steps 1 to 4.
2. Using the Down arrow key, scroll to Letter and press Enter.
3. Using the Down arrow key, scroll to the required document size and press Enter.

4. Press the Start button to send your document(s).

---

**Note**

After you have completed your fax operation, the machine will automatically return to the preset value.

---

## Fax Receiving

Your MFP is set to receive faxes automatically, if you wish to change the reception mode, refer to "Reception Mode" on page 68 for details.

### Automatic fax receive (default mode)

When the MFP is in automatic fax receive mode:

- When ringing - Receiving start is displayed on Screen.
- While it is receiving a Fax - Fax Receiving, sender's Fax. No., and the number of pages are displayed until the reception of data from all pages is complete.
- Upon completion of Fax Receiving - Sender's Fax no., the total number of received pages and Receiving OK are displayed for 3 seconds, and the display changes to the Mode Selection screen.
- When the machine is printing Fixed images, the screen displays are the same as those for printing.

---

**Note**

Cancelling is disabled while the machine is receiving a fax.

---

If fax receiving fails, an error message displays until you press the Stop button:

- If an error occurs while a fax is being received, fax communication-related errors are displayed.
- If an error occurs while a fax is printing, error messages displayed are the same as those in print mode.

### Manual Receive

Upon receiving an incoming call, the MFP will ring until you press the Start button to receive the fax.

Refer to "Reception Mode" on page 68 for details on enabling manual receive mode.

### Tel/Fax automatic switching

Telephone/Fax Mode (T/F): When incoming calls are a mixture of fax and telephone calls, your best choice is the Telephone/Fax Mode. In this mode, the machine detects whether the incoming call is a fax or voice call.

When the call is from another Fax machine, your machine will switch to fax mode and receive the message. When the call is a voice call, your machine will ring like a

telephone. If you do not answer, your machine will switch back to fax mode to allow the calling party to manually send a fax.

Refer to "Reception Mode" on page 68 for details on enabling Tel/Fax mode.

## **TAD interface**

Telephone Answering Device Mode (TAD): Use this mode if you want the machine and telephone answering machine to share the same phone line. Like Telephone/fax mode, the TAD mode detects whether an incoming call is fax or voice call. Refer to "Adding a telephone handset" on page 68 for more information.

To set up TAD mode:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Basic Setup and press Enter.
6. Using the Down arrow key, scroll to TAD Mode and press Enter.
7. Select the appropriate setting; Type1, Type2, Type3.
8. Press the Left arrow key to exit the menu.

Refer to "Reception Mode" on page 68 for details on enabling TAD mode.

## **DRD interface**

Distinctive Ring Detection Mode (DRD): This mode is programmed for the fax to answer only on a distinctive ring. You can have a single phone line to have two numbers with distinct rings, one for regular phone calls and one for fax. If the phone line is in use, and there is an incoming fax, the sender will receive a busy signal.

To set up DRD mode:

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Basic Setup and press Enter.
6. Using the Down arrow key, scroll to DRD Type and press Enter.
7. Select the appropriate setting; Type1, Type2, Type3, Type4.
8. Press the Left arrow key to exit the menu.

Refer to "Reception Mode" on page 68 for details on enabling DRD mode.

## Remote receiving

If you have an external telephone handset connected to your fax machine, you can instruct your fax machine to begin receiving by entering a three-digit code on your telephone keypad. This feature is useful when you answer a call on the external phone, but need to switch the line over to your fax machine.

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Basic Setup and press Enter.
6. Using the Down arrow key, scroll to Remote Receive No. and press Enter.
7. Select the appropriate setting; Off, 000, 111, 222, 333, 444, 555, 666, 777, 888, 999, \*\*\*, ###.
8. Press the Left arrow key to exit the menu.

Refer to "Reception Mode" on page 68.

## Faxing (MB470 MFP & MB480 MFP): Printing Reports

### Printing a fax activity report

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Press Enter to select System Setup.
5. Using the Down arrow key, scroll to Report Full Print and press Enter.
6. Using the Up arrow key, scroll to On and press Enter.
7. Press the Left arrow key twice to exit the menu.
8. Using the arrow keys, scroll to Print Information and press Enter.
9. Using the Down arrow key, scroll to Fax Activity Report and press Enter.
10. Press Enter to execute.

## Printing transmission reports

1. Using the Down arrow key, scroll to Menu and press Enter.
2. Using the Down arrow key, scroll to Admin Setup and press Enter.
3. Using the arrow keys and on-screen keypad, enter the Administrator password. Highlight Done and press Enter.
4. Using the Down arrow key, scroll to Fax Setup and press Enter.
5. Using the Down arrow key, scroll to Basic Setup and press Enter.
6. Using the Down arrow key, navigate to the required report and press Enter. Choose from:
  - MCF (Single Location) - this prints a transmission report after each fax.
  - MCF (Multi Location) - this prints a summary report detailing which numbers were successful and any that failed.
  - Error MCF - this prints a report after each failed fax transmission.
  - Image in MCF - this includes an image of the fax on each transmission report.
7. Using the Up arrow key, scroll to On and press Enter.
8. Press the Left arrow key to exit the menu.

# Faxing (MB470 MFP & MB480 MFP): Sending a Fax from your PC


---

## Note

You must have the fax driver installed on your PC. Download the latest fax driver from [www.okiprintingsolutions.com](http://www.okiprintingsolutions.com).


---

1. From your application's File menu, select Print.
2. In the Select Printer window, highlight the fax driver option.
3. Press the Preferences/Properties button to display the fax driver window.



4. On the Setup tab:
  - a. Select the appropriate media size from the drop-down menu.
  - b. Set the resolution to Fine, Normal or Fast.
  - c. Set the orientation to Portrait or Landscape.
5. On the Cover Sheet tab:
  - a. Set the cover sheet usage settings as appropriate.
  - b. Select a cover sheet format.
6. On the Sender tab:
  - a. Enter your name.
  - b. Enter your fax number.
  - c. If required select the Add an outside call number checkbox and enter Outside call number as appropriate.

**7. On the Recipient tab:**




- a. Click the Recipient...button.
  - b. Select a fax number from the Phone book panel on the right hand side. Refer to "Adding fax numbers to the phone book" on page 94
  - c. Click the Add button to add this number to the recipient list.
  - d. Repeat b and c as required to create the recipient list.
  - e. If you need to remove a number from the recipient list, highlight the appropriate name and then click the Delete button.
  - f. Once you have completed your list, click the OK button to close the Select Recipients window.
- 8.** Press the OK button to close the fax driver window.
- 9.** Press OK to start sending your fax.

## Using the Phone Book

### Adding fax numbers to the phone book

To add a fax destination number to the phonebook:

1. From your application's File menu, select Print.
2. In the Select Printer window, highlight the fax driver option.
3. Press the Preferences button to display the fax driver window.



4. Click the Phone book... button.  
*The phone book screen displays.*
5. Select FAX number -> New (Fax number).
6. Type in the fax number destination Name.
7. Type in the required FAX number.
8. If required, type in a Comment.
9. Press the OK button to save.

## Adding new groups numbers to the phone book

To add a new group to the phone book:

1. From your application's File menu, select Print.
2. In the Select Printer window, highlight the fax driver option.
3. Press the Preferences button to display the fax driver window.
4. Click the Phone book... button.

*The phone book screen displays.*

5. Select Fax number -> New (Group).
6. Type in the Group name.
7. if required, type in a Comment.
8. Add recipients to the group list:

---

### Note

Maximum 100 recipients in any one group.

---

- a. Select a fax number from the Phone book panel on the right hand side.

---

### Note

You can add a new fax number directly by clicking the New (FAX number)... button and adding an entry to the phone book panel.

---

- b. Click the Add -> button to add this number to the group list.
  - c. Repeat steps a and b as required to create the group list.
  - d. If you need to remove a number from the recipient list, highlight the appropriate name and then press the <- Delete button.
9. Once you have completed your list, press the OK button to close the New Group window.

## Importing and exporting fax numbers

By using the import, export functions, you can manage fax numbers in a phonebook created on another computer.

1. In Windows:

XP: select Start > Control Panel > Printer and Other Hardware > Printers and Faxes.

Server 2003: select Start > Printers and Faxes.

2000: select Start > Settings > Printers.

2. Right-click your machine icon and select Printer Preferences.
3. In the **Setup** tab, click the Phone Book button.

4. From the pull-down menu, click Tool > Export.
5. In the Export File screen, enter a name for the file and click the Save button. The phonebook is saved.
6. Import the saved phonebook file to the other computer:
  - a. In the fax driver installed on the computer that the phone book file was imported, start the phonebook in the same way, and click Tool > Import in the menu.
  - b. In the Import File screen, select a phone book file to import. When the Open button is clicked, data is imported to the phone book.

---

**Note**

Registration of groups cannot be exported. (Destinations included in the group are exported.)

If the same name is already included in the phonebook of the fax driver to import, it is skipped.

---

# Printer Settings in Windows

---

Your printer's operator panel menus provide access to many options.

The Windows printer driver also contains settings for many of these items. Where items in the printer driver are the same as those in the operator panel menus, and you print documents from Windows, the settings in the Windows printer driver will override those settings in the operator panel menus.


## **Printing preferences in Windows applications**

When you choose to print your document from a Windows application program a Print dialog box appears. This dialog usually specifies the name of the printer on which you will print your document. Next to the printer name is a Properties button.

When you click Properties a new window opens which contains a short list of the printer settings available in the driver, which you can choose for this document. The settings available from within your application are only those which you may want to change for specific applications or documents. Settings you change here will usually only last for as long as the particular application program is running.


# PCL emulation

## Setup tab



1. Paper size should be the same as the page size of your document (unless you wish to scale the printout to fit another size), and should also be the same as the size of paper you will feed into the printer.
2. You can choose the source of the paper to feed, which may be Tray 1 (the standard paper tray), Manual (MB460 MFP), Multi Purpose Tray (MB470 MFP, MB480 MFP), or Tray 2 (if you have the optional second paper tray installed). You can also click on the appropriate part of the screen graphic to select your preferred tray.
3. A variety of document finishing options can be selected, such as normal one page per sheet, or N-up (where N can be 2 or 4) for printing scaled down pages at more than one page per sheet.
4. Under 2-sided Printing, you can choose from auto or manual. Under manual 2-sided Printing you can choose to print on one side of a sheet only or to use 2-sided printing (duplex printing). Your printer allows you to carry out manual duplex printing, meaning you must pass the paper through the printer twice. For more information, see "2-sided (duplex) printing" on page 111. The Duplex Help button also offers guidelines on how to carry out manual duplex printing.
5. If you have changed some printing preferences before and saved them as a set, you can recall them to avoid having to set them individually each time you need them.
6. A single on-screen button restores the default settings.

## Job options tab




1. The output resolution of the printed page can be set as follows.
  - The ProQ1200 setting for Xxxxxn prints at 600 X 2400dpi. This setting requires the most printer memory and takes the longest to print. Your printed pages can be scaled to fit larger or smaller stationery. It is the best option for printing photographs.
  - The High Quality setting prints at 600 X 1200dpi for Xxxxxn and 1200 x 1200dpi for Xxxxxdn and Xxxxxdtn is the best option for printing vector objects such as graphics and text.
  - The Normal setting prints at 600 x 600dpi and is suitable for most printing jobs.
  - The Draft setting prints at 300 x 300dpi and is suitable for printing draft documents that contain mainly text. You can select Toner Saving to save toner for some print jobs.
2. Page orientation can be set to either portrait (tall) or landscape (wide). Both views can be rotated by 180 degrees.
3. You can print watermark text behind the main page image. This is useful for marking documents as draft, confidential, etc.

If you would like to print on special stationery, such as forms and letterhead, but do not want to use pre-printed stationery, you can create your own using Overlays. For more information on Overlays and Macros refer to "Overlays and Macros (Windows only)" on page 129. The Overlays button also offers guidelines on how to carry out manual duplex printing.

- 4.** In Raster (bitmap) mode, processing of the page image is done in the computer leaving little processing for the printer to do, although the file size may be large. In Vector mode, file sizes may be smaller and so transmission over a network, for example, may be faster. These effects are more pronounced for graphics printing than for text printing.
- 5.** You can select up to 999 copies to print consecutively, although you will need to top up the paper tray during such a long print run.
- 6.** Your printed pages can be scaled to fit larger or smaller stationery, within a range of 25% to 400% of the original size.
- 7.** A single on-screen button restores the default settings.

## Image tab




1. Dithering produces an intermediate greyscale by adjusting the combination of dots used in printing. Selecting a setting determines the degree of detail with which a graphics image will be printed. Mesh determines that a screen of dots is used for dithering while Line Art determines that an array of lines is used for dithering.
2. Select dithering texture by setting the size of dots used in the halftone screen.
3. Set this control to print greyscale effects in black without dithering. Select the check-box to disable greyscale printing or de-select the check-box to enable greyscale printing.
4. You can manually adjust lightness (the higher the setting the lighter the print) and contrast (the higher the setting the greater the contrast).
5. A single on-screen button restores the default settings.

## Setting from Windows control panel


When you open the driver properties window directly from Windows, rather than from within an application program, a somewhat more extensive range of settings is provided. Changes made here will generally affect all documents you print from Windows applications, and will be remembered from one Windows session to the next.

### General tab



1. This area lists some of the main features of your printer, including optional items.
2. This button opens the same windows as described earlier for items which can be set from within application programs. Changes you make here, however, will become the new default settings for all Windows applications.
3. This button prints a test page to ensure that your printer is working.

## Advanced tab



1. You can specify which times of day your printer will be available.
2. Indicates current priority, from 1 (lowest) to 99 (highest). Highest priority documents will print first.
3. Specifies that documents should be spooled (stored in a special print file) before being printed. The document is then printed in the background, allowing your application program to become available more quickly. Options follow:


This specifies that printing should not start until the last page has been spooled. If your application program needs a lot of time for further computation in the middle of printing, causing the print job to pause for more than a short period, the printer could prematurely assume that the document has finished. Selecting this option would prevent that situation, but printing will be completed a little later, as the start is delayed.

This is the opposite choice to the one above. Printing starts as soon as possible after the document begins spooling.
4. This specifies that the document should not be spooled, but printed directly. Your application will not normally be ready for further use until the print job is complete. This requires less disk space on your computer, since there is no spool file.
5. Directs the spooler to check the document setup and match it to the printer setup before sending the document to print. If a mismatch is detected, the document is

held in the print queue and does not print until the printer setup is changed and the document restarted from the print queue. Mismatched documents in the queue will not prevent correctly matched documents from printing.

- 6.** Specifies that the spooler should favour documents which have completed spooling when deciding which document to print next, even if completed documents are lower priority than documents which are still spooling. If no documents have completed spooling, the spooler will favour larger spooling documents over shorter ones. Use this option if you want to maximize printer efficiency. When this option is disabled the spooler chooses documents based only on their priority settings.
- 7.** Specifies that the spooler should not delete documents after they are completed. This allows documents to be re submitted to the printer from the spooler instead of printing again from the application program. If you use this option frequently it will require large amounts of disk space on your computer.
- 8.** Specifies whether advanced features, such as pages per sheet, are available, depending on your printer. For normal printing keep this option enabled. If compatibility problems occur you can disable the feature. However, these advanced options may then not be available, even though the hardware might support them.
- 9.** This button provides access to the same setup windows as when printing from applications. Changes made via the Windows Control Panel become the Windows default settings.
- 10.** You can design and specify a separator page that prints between documents. This is particularly useful on a shared printer to help each user find their own documents in the output stack.


## Device options tab



In this window you can select which optional upgrades are installed on your printer. See the chapter entitled "Installing options".


# PS emulation (MB470 MFP & MB480 MFP)

## Layout tab




1. Page orientation can be set to portrait (tall), landscape (wide) or landscape rotated by 180 degrees.
2. Print on both sides (duplex printing) can be set to long edge or short edge of the document.
3. Printed page order can be set as front to back or back to front of the document.
4. Set the number of pages to be printed on a single sheet. You can also set it to print a booklet.

5. Click the Advanced button to be able to set further document options as follows:




- Select the required printed paper size.
- You can substitute another font for TrueType Font.
- You can set other document options as required, including PostScript options and printer features.

## Paper/Quality tab



You can set the paper source or leave it as automatic selection and by using the Advanced button you have access to the same set of options as described above for the **Layout** Tab.

## Job options tab




1. The output resolution of the printed page can be set as follows.
  - The High Quality setting prints at 1200 x 1200dpi for Xxxxxdn and Xxxxxdtn and is the best option for printing vector objects such as graphics and text.
  - The Normal setting prints at 600 x 600dpi and is suitable for most printing jobs. You can select Toner Saving to save toner for some print jobs.
2. You can print watermark text behind the main page image. This is useful for marking documents as draft, confidential, etc.

If you would like to print on special stationery, such as forms and letterhead, but do not want to use pre-printed stationery, you can create your own using Overlays. For more information on Overlays and Macros refer to "Overlays and Macros (Windows only)" on page 129. The Overlays button also offers guidelines on how to carry out manual duplex printing.
3. You can select up to 999 copies to print consecutively, although you will need to top up the paper tray during such a long print run.
4. Your printed pages can be scaled to fit larger or smaller stationery.
5. Using the Advanced button gives you access to the facility to set mirror image printing and negative image printing.
6. A single on-screen button restores the default settings.

## Settings from the Control Panel

The main tabs are the **General Tab**, **Advanced Tab** and **Device Settings Tab**. The General and Advanced tabs are the same as for PCL emulation described earlier.

### Device settings tab



1. You can set the desired paper sizes in each of the available paper feed trays.
2. You can make a variety of font settings depending on your application.
3. You can set which optional upgrades are installed on your printer. See the chapter entitled "Installing options".

## 2-sided (duplex) printing

The duplex unit adds the function of two-sided printing, using less paper and making large documents easier to handle. It also enables booklet printing, which uses even less paper.

---

### Note

The steps in the process relate to Windows XP PCL. Other operating system windows may appear slightly different, but the principles are the same.

---

- For Letter, A4, Legal 13, 13.5 and 14 and Custom paper sizes
- Paper stocks from 20 to 28 lb. US Bond (75 - 105 g/m<sup>2</sup>).

### To carry out Duplex Printing:

1. Select File > Print and click the Properties button.
2. Select the input tray (Tray1, Tray2 [optional], Multi Purpose Tray) from the Source drop down.
3. In the Duplex printing drop down menu, select either Long Edge (Auto) or Short Edge (Auto) according to your printing preferences.
4. If you require further information, click the Duplex Help button.
5. Click the Print button.

# Printer settings in Mac OS X

---

The information in this section is based on Mac OS X Tiger (10.4). Other versions may appear slightly different, but the principles are the same.


## PCL emulation

### Setting printing options

You can choose your printer and select options for how you want your documents to print from the Print dialog box.


To set your printer options:

1. Open the document you want to print.
2. To change the paper size or page orientation, select File > Page Setup. For a description of each option, see "Page setup options" on page 114



3. Close the Page Setup dialog box.
4. Select File > Print.
5. Select your printer from the Printer drop-down menu.

6. To change any printer driver settings, select the required options from the Settings drop-down menu. You can select more options from the Copies & Pages menu. For a description of these options, see "Print Options" on page 115




7. Click the Print button.

## Saving driver settings

You can save a set of printer driver options to use for future documents.

1. Open the document you want to print.
2. To change the paper size or page orientation, select File > Page Setup.



3. Select Save As Default from the Settings drop-down menu.

4. Select File > Print.
5. To save the current printer driver settings as a preset, select Save As from the Preset menu.
6. Enter a name for your preset and click OK.


## Changing the Default Printer and Paper Size

The following steps describe how to change your default printer and the paper size options.

1. Select Apple menu > System Preferences.
2. Click the Print & Fax icon.
3. Select your printer in the Selected Printer in Print Dialog drop-down menu.
4. Select your required paper size in the Default Size in Page Setup drop-down menu.

## Page setup options

This section provides a description of the page setup options available to you.



### Page attributes

You can select Save As Default to use the current Page Setup settings as a standard for all documents.

### Format for

Allows you to select your printer model before changing options such as Paper Size and Orientation.

## Paper size

Select a paper size to match your documents and the paper loaded in the printer. The paper margin is 4.2mm at all edges. To specify your own paper sizes, select **Manage Custom Sizes...**

## Scale


You can scale documents up or down to fit onto different paper sizes. To fit your document on a specific paper size, select Options in the Paper Handling drop-down menu in the Print Options dialog box (see "Print Options" on page 115).

## Orientation

You can select a portrait or landscape option. When using landscape, you can rotate the document 180 degrees.

## Print Options

### Copies & Pages



The screenshot shows the 'Copies & Pages' section of a print dialog box. At the top, there are three dropdown menus: 'Printer' set to 'My Printer', 'Presets' set to 'Standard', and 'Copies & Pages' (which is currently selected). Below these, the 'Copies' field is set to '1' and the 'Collated' checkbox is checked. The 'Pages' section has the 'All' radio button selected, and the 'From' and 'to' fields are both set to '1'. At the bottom of the dialog, there are buttons for '?', 'PDF', 'Preview', 'Cancel', and 'Print'.


### Copies

This option allows you to enter the number of copies to print. If you select Collate, all pages of the document will print before the next copy prints.

### Pages

You can select whether to print all pages of a document or just a section of it.

## Layout



### Pages per sheet


You can shrink multiple pages and print them on a single sheet of paper. For example, choosing 4-up will tie four of your document's pages across a single sheet of paper.

You can control the order in which the documents are tiled and also choose to surround each document page with a border.

### Two-sided

You cannot use the two sided printing options in this panel. Use the options in "2-sided (duplex) printing" on page 111 instead.


## Scheduler



This option lets you choose whether to print your document immediately, or defer printing until later. You can also assign a priority to a print job.

These features are useful if you are printing large documents that take a long time to print.

## Paper Handling



### Page order

You can choose to print your document in the normal page order (1,2,3...) or reverse order (...3,2,1).


### Print

This option allows you to choose whether to print only odd or even number of pages. This is useful if you are using manual duplex for which you first print all odd pages, re-insert the paper in the printer and then print all even pages.

### Destination paper size


Scale documents to fit on the size of paper in your printer. For example, you can take a document formatted for A3 and print it on A4 paper using an A4 printer.

## Cover page



Choosing a cover page may help you identify your printed document in a large pile of paper. This is useful in a busy office with many people sharing the printer.

## Duplex



Using the duplexer, you can print on both sides of the paper.


Long Edge Binding prints pages that read like a normal book.



Short Edge Binding prints pages that read like a notepad.




## Paper source



This option allows you to select the paper tray to use for your print job.

## Print quality




**MB460 MFP**



**MB470 MFP & MB480 MFP**

Use this option to select the print resolution. The ProQ1200 (MB460 MFP, MB470 MFP & MB480 MFP) and High Quality (MB470 MFP & MB480 MFP) setting produces the best graphic images, but these images take longer to print.

## Effects



Dithering produces an intermediate greyscale by adjusting the combination of dots used in printing. Selecting a setting determines the degree of detail with which a graphics image will be printed. Mesh determines that a screen of dots is used for dithering while Line Art determines that an array of lines is used for dithering.

Select dithering texture by setting the size of dots used in the halftone screen.

Adjust the brightness or contrast based on the original quality of the document.

# Printer setup options

## Printer options

Printer: My Printer  
Presets: Standard  
Printer Options  
Density: Normal (0)  
Weight: Medium Light (67 - 73 gm2)  
Toner save: Off  
 Auto tray switch  
 Paper size check  
? PDF Preview Cancel Print

**MB460 MFP**

Printer: My Printer  
Presets: Standard  
Printer Options  
Density: Normal (0)  
Weight: Medium Light  
Toner save: Off  
 Auto tray switch  
 Paper size check  
 Feed manually from Multi-purpose tray  
? PDF Preview Cancel Print

**MB470 MFP/MB480 MFP**

### Density

Select the density from Lightest (-2) to Darkest (+2) depending on the quality of the original document.

### Weight

Select the thickness or type of paper in the printer. It is important to set this correctly as it affects the temperature at which the toner is fused to the paper. For example, if you are printing on normal A4 paper, do not select Labels or Transparency as this may cause toner smearing and paper jam.

### Toner Save

Toner Save uses less toner when printing your document. This is best suited to draft text documents as it lightens the print significantly.

### Auto Tray Switch

If the printer runs out of paper in the current tray, the Auto Tray Switch automatically changes to a tray that has the same type of paper and continues printing.

### Paper size check


Select Paper Size check if you want the printer to warn you when the document paper size is different from the paper in the printer.

A warning message is displayed and printing continues when you load the correct paper in the paper tray and press **START**. When this option is deselected, the printer uses the paper loaded in the selected tray regardless of the document size.

## Feed manually from Multi-purpose tray (MB470 MFP & MB480 MFP)


Select this option if you want the printer to wait until you press the START button when feeding from the Multi-purpose Tray. This can be useful if printing envelopes.

## Print control



If you are using the Windows Print Control Server software to manage printers, enter your assigned user name and ID. This information is sent to the printer with your print job and is recorded by the printer.

## Summary



This option displays a summary of all selected print options for the current job.


# PS emulation (MB470 MFP & MB480 MFP)

## Copies & pages

Refer to “Copies & Pages” on page 115.

## Layout

Refer to “Pages per sheet” on page 116.



The Two-sided option is used for Duplex printing. Long-edged Binding prints pages that read like a normal book. Short-edged Binding prints pages that read like a notepad.

## Scheduler

Refer to “Scheduler” on page 117.

## Paper handling

Refer to “Paper Handling” on page 118.

## Cover page

Refer to “Cover page” on page 119.

## Error Handling



### Postscript errors

If an error occurs and stops the print job, you can use select the Print detailed report under Error Handling, which will print the error page in detail. This will help you identify the error and take suitable action.

### Tray switching

If the printer runs out of paper in the current tray, the Auto Tray Switch automatically changes to a tray that has the same type of paper and continues printing.

By selecting Display alert, a pop-up box will display on your application if there is a mismatch between the tray settings and paper size settings.

## Paper Feed




If you want the first page of a document printed on a different media, you can load the special media in the Multi-purpose tray and select the first page to be printed by

setting Multi-purpose tray as the source. The remaining pages of the document can be loaded in the cassette tray and you can set that as the paper source. The entire document will be printed in one print job.

## Printer Features

### Paper input options



### Paper size check

Select Paper Size check if you want the printer to warn you when the document paper size is different from the paper in the printer.

A warning message is displayed and printing continues when you load the correct paper in the paper tray and press Start. When this option is deselected, the printer uses the paper loaded in the selected tray regardless of the document size.


### Media Type

Specify the appropriate weight and kind of paper you are using. Do not choose Label or Transparency when printing on plain paper. This will cause paper jam or print quality problems.

### Multipurpose tray is handled as manual feed

Select this option if you want the printer to wait until you press the START button when feeding from the Multi-purpose Tray. This can be useful if printing envelopes.

## Job options



### Quality

Use this option to select the print resolution; 600 x 600dpi (normal printing), 1200 x 1200 (choose this for high quality print). The high quality print resolution requires a larger amount of disk space and takes longer to print.

### Toner saving

Uses less toner when printing your document. This is best suited to draft text documents as it lightens the print significantly.

### Page rotate

Select Page rotate to turn the text and images 180 degrees and point them across the length of the page.

### Adjust ultra fine lines

If you are printing a drawing and want to emphasize the pen width of very fine lines, select this option to improve the appearance of the lines. However, in some applications, if this options is selected and you are printing barcodes, the spaces in the barcode becomes too narrow. De-selecting this option resolves this problem.

### Summary

This option displays a summary of all selected print options for the current job.

## Cancelling a print job

You can cancel a print job from your software application, from the print queue or by using the **STOP** button on your printer.

PRINTING STATE	HOW TO CANCEL
Document has not started printing	Try to cancel printing job within software application
Document is waiting in a print queue	Delete print job from Print Queue. You can access the print queue from the System Tray in Windows or the Print Center Queue in Mac.
Document has started printing	Press the <b>STOP</b> button on your printer. Any pages that are already moving through the printer will be printed. You will need to press <b>STOP</b> for each print job you wish to stop.

# Overlays and Macros (Windows only) \_

## What are overlays and macros?

If you would like to print on special stationery, such as forms and letterhead, but do not want to use pre-printed stationery, you can create your own using these advanced features.

You can use PostScript overlays to generate all your special stationery and store it in the printer for use whenever you need it. If you have chosen to install the PCL driver, macros perform a similar function.

You can create several overlays or macros, and combine them in any way you like to produce a variety of forms and other special stationery. Each image can be printed on just the first page of a document, on all pages, on alternate pages, or just the pages that you specify.

## Creating PostScript overlays


Three steps are required to create an overlay:

1. Create the form data using your own application software and print it to a printer (.PRN) file.
2. Use the Storage Device Manager utility software supplied on CD with your printer to create a "project file," import the .PRN file(s), and download the generated filter (.HST) file to the printer. The project file will contain one or more overlay images which are functionally related, such as the cover page and the continuation page images for business letters.
3. Use downloaded files to define your overlays ready for use when printing your documents.


When printing overlay files to disk, do not select any special features, such as two-sided printing or multiple copies. These are not appropriate to overlays, they apply only to your final documents.

## Creating the overlay image

1. Use your preferred application, perhaps a graphics program, to create the required overlay image and save it.
2. Open your application's **Print...** dialog.
3. Make sure that the selected printer name (1) is that of your PostScript printer driver.
4. Select the **Print To File** (2) option.
5. Click the **Properties** button (3) to open the Document Properties window.



6. On the **Overlay** tab, choose **Create Form** from the drop-down list (4).
7. Click **OK** to close the Document Properties window.
8. Click **OK** again to close the Print dialog.
9. When prompted for a print file name, enter a meaningful name with the extension.PRN.
10. Close your application.



## Create and download the project

1. From the Windows Start menu, start Storage Device Manager (SDM) and allow SDM to discover the printer.
2. Choose Projects > Add File to Project.
3. Set the Files of Type drop-down list to PRN Files(\*.prn).
4. Navigate to the folder where the.PRN files are stored and select one or more of these to include in your overlay set.

You can have more than one printer (.PRN) file in a project. For example, one for top pages and another for continuation pages. Use standard Windows techniques (Shift or Ctrl keys) to select multiple files simultaneously if you need to.

5. Click Open to add these files to the current project.
6. When a message box appears confirming that a filter file has been created, click **OK** to clear the message.
7. The project window will display one.HST file for each printer file added. Make a careful note of each of these names. Ensure that you note them *exactly* as they appear, they are case sensitive, and you will need them later.
8. Choose Projects > Save Project and enter a meaningful name (e.g. "Letter Stationery") so that you can recognize it later if you want to modify it.
9. Choose Projects > Send Project Files to Printer to download the project to the printer.

If you have a hard disk in the printer, SDM will automatically download files to it. If not, SDM will download files to flash memory. If you have a hard disk but still prefer to download to flash memory, double-click the file name in the Project window and under Volume, type in %Flash0% and then click OK.

10. When the message "Command Issued" appears confirming that the download is complete, click **OK** to clear the message.

## Test printing the overlay


1. Click on the printer icon for the relevant printer and choose Printers > Test Form.

2. In the Test PostScript Form window, to test each overlay select it and click OK. There will be a short pause while the printer processes the form, and then it will print.
3. When each overlay has been tested, click **Exit**.
4. Click the standard Windows Close (X) button, or choose Projects > Exit to close Storage Device Manager.

## Defining overlays

This is the final step before the new overlays are ready for use.

1. Open the Printers (called "Printers and Faxes" in Windows XP) window via the **Start** menu or the Windows Control Panel.
2. Right-click on the Relevant PostScript printer icon and choose **Printing Preferences** from the pop-up menu.
3. On the Overlay tab, click the New button.
4. In the Define Overlays window, enter a suitable name (2) for this overlay and choose which page(s) (3) of your documents will use this overlay.
5. Enter the name of the overlay file (4) *exactly* as it appeared in the Storage Device Manager project window. Remember that this name is case sensitive.



If you forgot to note the overlay names when you created them, you can find them using Storage Device Manager to view the project file, or the printer's Information Menu to print a file list and identify them from there.

6. Click Add (5) to add this overlay into the defined overlays list.
7. Click OK to close the Define Overlay window.

The new overlay now appears in the Defined Overlays list in the printer properties window.

8. Repeat the above procedure if you wish to define more overlays.
9. When done, click OK to close the printer properties window.


Your new overlays are now ready and available to be used for any future documents you wish.

## Printing with PostScript overlays

Once you have defined your overlays you are ready to use them for any documents you wish. The example illustrated here uses two overlays for business letters. The first prints on just the top page, and the second prints on any or all subsequent pages.

1. Prepare your document in the normal way using your own application software. Remember, if necessary, to format the document so that it will fit within the appropriate space.

2. Open your application's Print... dialog and choose any options you will require, ensuring that the target printer is your PostScript printer driver in which the overlays have been defined.
3. Click the Properties button to open the Printing Preferences window.
4. On the Overlays tab, choose Use Overlay from the drop-down list (1).
5. Click on the first overlay (2) you wish to use. In this example it is the Cover Page overlay. Then click the **Add** button (3).
6. If you want to use another overlay, in this case it is the Continuation page, click the second overlay (4) and then click the Add button (3) again.
7. When you have selected all the overlays you want to use for this document, click **OK**.
8. Finally, in your application's print dialog, click OK to begin printing.



## Creating PCL Overlays


Three steps are required to create an overlay:

1. Create the form data using your own application software and print it to a printer (.PRN) file.
2. Use the Storage Device Manager utility software supplied on CD with your printer to create a "project file," import the .PRN file, and download the generated filter (.BIN) files to the printer.
3. Use downloaded files to define your overlay ready for use with any future document.

When printing files to disk, do not select any special features, such as two-sided printing or multiple copies. These are not appropriate to macros, they apply only to your final documents.

## Creating the overlay image

1. Use your preferred application, perhaps a graphics program, to create the required image and save it.
2. Open your application's Print... dialog.
3. Make sure that the selected printer name (1) is that of your PCL printer driver.
4. Select the Print To File (2) option.
5. When prompted for a print file name, enter a meaningful name with the extension .PRN .
6. Close your application.



## Create and download macros

1. From the Windows Start menu, start Storage Device Manager (SDM) and allow SDM to discover the printer.
2. Choose Projects > New Project to start a new project.
3. Choose Projects > Filter Macro File. The Filter Printer Patterns dialog box appears. Make any adjustments in the settings that you need and then click OK.

**Example:** If you create a black oval in MS Paint and leave all the color command filters checked, the black oval will print as a black rectangle when the overlay is used. To maintain the oval shape, turn off (deselect) the "Configure Image Data," "Palette ID" and "Palette Control" filters.

4. Set the Files of Type drop-down list to PRN Files(\*.prn).
5. Navigate to the folder where the overlay .PRN files are stored and select one or more of these to include in your overlay set.

You can have more than one macro file in a project. For example, one for top pages and another for continuation pages. Use standard Windows techniques (Shift or Ctrl keys) to select multiple files simultaneously if you need to.

6. Click Open to add these files to the current project. (You can also drag and drop files from Windows Explorer directly into the project window if you prefer.) When a message box appears confirming that a filter file has been created, click **OK** to clear the message.
7. The project window will display one .BIN file for each printer file added. Make a careful note of the name and ID number for each of the files. You will need them later.

If you wish to edit the names or ID numbers, double-click the file entry and edit the details.

Note that the names are case sensitive.

8. Choose Projects > Save Project and enter a meaningful name (e.g. "Letter Stationery") so that you can recognize it.
9. Choose Projects > Send Project Files to Printer to download the project to the printer.
10. When the message "Command Issued" appears confirming that the download is complete, click OK to clear the message.


## Test printing the macro

1. Choose Printers > Test Macro.
2. In the Test Macro window, enter its ID number and click OK. After a short pause the printer will print the macro.
3. When each macro has been tested, click Exit.
4. Click the standard Windows Close (X) button, or choose Projects > Exit to close Storage Device Manager.


## Defining overlays

This is the final step before the new overlays are ready for use.

1. Open the Printers (called "Printers and Faxes" in Windows XP) window via the **Start** menu or the Windows Control Panel.
2. Right-click on the Relevant PostScript printer icon and choose Printing Preferences from the pop-up menu.
3. On the Job Options tab, click the Overlay button.
4. In the Overlay window, Click the Define Overlays button (1).



5. In the Define Overlays window, enter the name (a) and ID (b) of the required overlay, and define which page(s) (c) of your documents will use this overlay. Then click the Add button (3) to add this overlay to the list of defined overlays. Repeat for any other related overlays. When done, click the Close button (4) to close the window.



The example illustrated shows two overlays defined, one for a cover page and one for continuation pages.

Remember that names and IDs of overlay files must be entered *exactly* as they appeared in the Storage Device Manager project window. Remember also that names are case sensitive.

If you forgot to note the overlay name or ID when you created them, you can find them using Storage Device Manager to view the project file, or the printer's Information Menu to print a file list and identify them from there.

The new overlays will now appear in the Defined Overlays list in the printer properties window.


6. When done, click **OK** to close the printing preferences window.

Your new overlays are now ready and available to be used for any future documents you wish.

## Printing with PCL overlays

Once you have defined your overlays you are ready to use them for any documents you wish. The example illustrated here uses two overlays for business letters. The first prints on just the top page, and the second prints on any or all subsequent pages.

1. Prepare your document in the normal way using your own application software. Remember, if necessary, to format the document so that it will fit nicely within the plain areas on your letterhead overlay.
2. Open your application's **Print...** dialog and choose any options you will require, ensuring that the target printer is your PCL printer driver in which the overlays have been defined.
3. Click the Properties button to open the Printing Preferences window.
4. On the Overlay tab, check the Use active overlays checkbox (1).
5. In the Defined Overlays list, click on the first overlay (2) you wish to use, and click the Add button (3) to add it to the Active Overlays list. (If you want a reminder of how this overlay looks, click the Test Print button.)
6. If you want to use another overlay with this document, in this example it is the "Continuation Page" overlay, click this overlay (4) in the list of defined overlays, and then click the Add button (3) again to add the second overlay to the list of active overlays.
7. When the list of active overlays contains all the items you want to use, click OK.
8. Finally, click the Print button in your application's Print dialog to begin printing your document.



# Maintenance

---

## Consumables

---

### Note

When the on-screen display indicates that the toner is low, or if print appears faded, first open the top cover and try tapping the cartridge a few times to evenly distribute the toner powder. This will enable you to obtain the best “yield” from your toner cartridge.

---

ITEM	LIFE	ORDER NO.
Toner standard • MB460 MFP • MB470 MFP • MB480 MFP	3,500 A4@ ISO/IEC19752	43979101
Toner high capacity • MB460 MFP • MB470 MFP • MB480 MFP	7,000 A4@ ISO/IEC19752	43979201
Toner high capacity • MB480 MFP only	12,000 A4@ ISO/IEC19752	43979215
Image Drum	25,000 A4 pages	43979001

Only use genuine original consumables to ensure the best quality and performance from your hardware.

# Replacing consumable items

## Toner cartridge replacement

### **Caution!**

To avoid toner wastage and possible toner sensor errors, do not change the toner cartridge until "TONER EMPTY" is displayed.

Have a sheet of paper handy so that you have somewhere to place the used cartridge while you install the new one.

Dispose of the old cartridge responsibly, inside the pack that the new one came in. Follow any regulations, recommendations, etc., which may be in force concerning waste recycling.


If you do spill any toner powder, lightly brush it off. If this is not enough, use a cool, damp cloth to remove any residue.

Do not use hot water, and *NEVER* use solvents of any kind. They will make stains permanent.


### **Warning!**

**If you inhale any toner or get it in your eyes, drink a little water or bathe your eyes liberally in cold water. Seek medical attention immediately.**

1. Lift the Scanner.




2. Press the cover release (a) and open the top cover (b) fully.




### **Warning!**

**If the MFP has been powered on, the fuser may be hot. This area is clearly labelled. Do not touch.**

3. Pull the colored toner release lever (1) on the cartridge to be replaced fully towards the front of the MFP.



4. Lift the right-hand end of the cartridge and then draw the cartridge to the right to release the left-hand end as shown, and withdraw the toner cartridge out of the MFP.




5. Put the cartridge down gently onto a piece of paper to prevent toner from marking your furniture.


**Caution!**

The green image drum surface is very delicate and light sensitive. Do not touch it and do not expose it to normal room light for more than 5 minutes. If the toner cartridges need to be out of the MFP for longer than this, please lower the top cover. Never expose the drum to direct sunlight or very bright room lighting.


6. Remove the new cartridge from its box but leave its wrapping material in place for the moment.
7. Gently shake the new cartridge from end to end several times to loosen and distribute the toner evenly inside the cartridge.




8. Remove the wrapping material and peel off the adhesive tape from the underside of the cartridge.



9. Holding the cartridge by its top centre with the colored lever to the right, lower it into the printer over the image drum unit from which the old cartridge was removed.
10. Insert the left end of the cartridge into the top of the image drum unit first, pushing it against the pins on the drum unit, then lower the right end of the cartridge down onto the image drum unit.




**11.** Pressing gently down on the cartridge to ensure that it is firmly seated, push the colored lever towards the rear of the MFP. This will lock the cartridge into place and release toner into the image drum unit.



**12.** Close the top cover and press down firmly so that the cover latches closed.

**13.** Gently lower the scanner.




## Image drum replacement




**Caution!**  
Static sensitive devices, handle with care.

1. Lift the scanner.




2. Press the cover release (a) and open the top cover (b) fully.



### ***Warning!***

**If the MFP has been powered on, the fuser will be hot. This area is clearly labelled. Do not touch.**

3. Holding it by its top centre, lift the image drum, complete with its toner cartridge, up and out of the MFP.




4. Put the cartridge down gently onto a piece of paper to prevent toner from marking your furniture and to avoid damaging the green drum surface.

**Caution!**

The green image drum surface at the base of the cartridge is very delicate and light sensitive. Do not touch it and do not expose it to normal room light for more than 5 minutes. If the drum unit needs to be out of the MFP for longer than this, please wrap the cartridge inside a black plastic bag to keep it away from light. Never expose the drum to direct sunlight or very bright room lighting.


5. With the colored toner release lever to the right, pull the lever towards you. This will release the bond between the toner cartridge and the image drum cartridge.
6. Lift the right-hand end of the cartridge and then draw the cartridge to the right to release the left-hand end as shown, and withdraw the toner cartridge out of the image drum cartridge. Place the cartridge on a piece of paper to avoid marking your furniture.
7. Take the new image drum cartridge out of its packaging and place it on the piece of paper where the old cartridge was placed. Keep it the same way round as the old unit. Pack the old cartridge inside the packaging material for disposal.

- 8.** Place the toner cartridge onto the new image drum cartridge as shown. Push the left end in first, and then lower the right end in. (It is not necessary to fit a new toner cartridge at this time unless the remaining toner level is very low.)
- 9.** Push the colored release lever away from you to lock the toner cartridge onto the new image drum unit and release toner into it.
- 10.** Holding the complete assembly by its top centre, lower it into place in the MFP, locating the pegs at each end into their slots in the sides of the MFP cavity.



- 11.** Close the top cover and press down firmly so that the cover latches closed.

**12.** Gently lower the scanner.



---

**Note**

If you need to return or transport this product for any reason, please make sure you remove the image drum unit beforehand and place in the bag provided. This is to avoid toner spillage. Refer to "Appendix A - Moving and transporting" on page 176 for details.

---

# Cleaning


From time to time print “debris” such as ink, toner and paper dust will accumulate in the ADF and the document glass from documents which have been copied.

## **Caution!**

**Use a clean, moist, lint-free cloth for cleaning. Do not use benzine, thinners or alcohol as a cleaning agent.**

## **...the unit casing**

1. Switch off the MFP.
2. Wipe the unit surface with a soft cloth moistened sparingly with water or neutral detergent.




3. Use a soft dry cloth to dry the unit surface.
4. Turn on the MFP.

## **...the paper path in the ADF**


If marks are found on an image, which has been read by the ADF, or the ADF does not feed documents smoothly, follow the cleaning procedure below.

1. Switch the MFP OFF.
2. Open the ADF top cover.

3. Pinch the ADF lock lever and swing the feeder mechanism up until it is locked.



4. Moisten a soft clean lint free cloth and remove any marks by wiping the cloth in the direction of the arrow, as shown.




5. Return the feeder mechanism to its original position.
6. Close the ADF top cover.

### **... the underside of the ADF**

1. Open the document cover.

2. Moisten a soft, clean, lint free cloth and remove any marks as shown.




3. Close the document cover.

### **...the document glass**

The document glass needs to be cleaned occasionally to ensure optimum image quality and performance.

1. Open the document cover.




2. Moisten a soft, clean, lint-free cloth and remove any marks, as shown.
3. Close the document cover.

## ...the LED head


Clean the LED head when printing does not come out clearly, has white lines or when text is blurred.

There is no need to switch the MFP off to clean the lens.


1. Lift the scanner.



2. Press the cover release (a) and open the top cover (b) fully.




3. Moisten a soft, clean, lint-free cloth and gently wipe the LED head surface.



**Caution!**

Do not use methyl alcohol or other solvents on the LED head as damage to the lens surface will occur.

4. Close the top cover and press down firmly so that the cover latches closed.
5. Gently lower the scanner.



# Installing options

The following options are available to extend the performance of your printer:

- 64, 256 RAM DIMM: to extend the main memory of your printer and speed up the processing of large files.
- Second paper tray: to increase your printer's paper handling capacity by 530 sheets (75 g/m<sup>2</sup>)

## Option order numbers

OPTIONS	ORDER NUMBER
64MB RAM DIMM	44029504
256MB RAM DIMM	44029509
Second Paper Tray	43990707

## Installation procedure

To install any of the above options, follow the detailed installation sheet that accompanies the option.

# Troubleshooting

---

## Clearing paper jams


Provided that you follow the recommendations in this guide on use of print media, and you keep the media in good condition prior to use, your MFP should give years of reliable service. However, paper jams occasionally do occur, and this section explains how to clear them quickly and simply.

Jams can occur due to paper misfeeding from a paper tray or at any point on the paper path through the printer or scanner ADF. When a jam occurs, the MFP immediately stops. If printing multiple pages (or copies), do not assume that, having cleared an obvious sheet, others will not also be stopped somewhere along the path. These must also be removed in order to clear the jam fully and restore normal operation.

### In the scanner ADF section...


In the event of a paper jam, follow the procedures below to remove the paper:

1. Lift the ADF cover (1).



2. Remove any loose paper from the entry to the sheet feeder.
3. If there is any paper trapped in the feed mechanism:
  - a. Lift the feeder mechanism by the coloured tab (2).


- b. Remove any paper from ADF mechanism.




4. Lower the ADF cover.
5. Press the Stop button to restore the scanning head to the correct position.

### **In the printer section...**


1. Lift the scanner.



2. If a sheet is well advanced out of the top of the printer, simply grip it and pull gently to draw it fully out. If it does not remove easily, do not use excessive force. It can be removed from the rear later.




3. Press the cover release (a) and open the MFP's top cover (b) fully.



**Warning!**

**If the MFP has been powered on, the fuser will be hot. This area is clearly labelled. Do not touch.**

4. Holding it by its top centre, lift the image drum, complete with its toner cartridge, up and out of the printer.




5. Put the cartridge down gently onto a piece of paper to prevent toner from marking your furniture and to avoid damaging the green drum surface.


***Caution!***

The green image drum surface at the base of the cartridge is very delicate and light sensitive. Do not touch it and do not expose it to normal room light for more than 5 minutes. If the drum unit needs to be out of the MFP for longer than this, please wrap the cartridge inside a black plastic bag to keep it away from light. Never expose the drum to direct sunlight or very bright room lighting.

6. Remove any jammed sheets from the paper path.




7. Holding the complete assembly by its top centre, lower it into place in the MFP, locating the pegs at each end into their slots in the sides of the MFP cavity.



8. Lower the top cover but do not press down to latch it closed yet. This will protect the drums from excessive exposure to room lighting while you check the remaining areas for jammed sheets.
9. Open the rear cover and check for a sheet of paper in the rear path area.


Pull out any sheets found in this area.



If the sheet is low down in this area and difficult to remove, it is probably still gripped by the fuser. In this case raise the top cover, reach around and press down on the fuser pressure release lever.

- 10.** If you are not using the rear exit tray, close it once paper has been removed from this area.

**11.** Remove the Duplex Unit (1) and check for any paper in this area. Remove any paper and replace the duplex unit..



---


**Note**

If the paper is not advanced enough to grip, push the cover (2) in the arrow direction, raise it and remove the paper. Refit duplex unit.

---


**12.**Open the Multi Purpose Tray.

Remove any paper that you find and then close the tray.




**13.**Pull out the paper tray and remove any paper from the underside of the printer. Ensure that all paper is stacked properly, is undamaged, and that the paper

guides are properly positioned against the edges of the paper stack. When satisfied, replace the tray.



**14.**Close the top cover and press down firmly at both sides so that the cover latches closed.

**15.**Gently lower the scanner.



## Dealing with unsatisfactory printing

SYMPTOMS	POSSIBLE CAUSES	STEPS TO TAKE
Vertical white lines can be seen on the printed page.	The LED head is dirty.	Wipe the LED head with a soft, lint-free cloth.
	The toner is low.	Open the top cover and tap the cartridge a few times to evenly distribute any remaining toner. If symptoms persist, replace the toner cartridge.
	Foreign materials may be present in the image drum.	Replace the image drum cartridge.
	Light-shielding film of the image drum cartridge is dirty.	Wipe the film with a soft, lint-free cloth.
Printed images are fading vertically.	The LED head is dirty.	Wipe the LED head with a soft, lint-free cloth.
	The toner is low.	Open the top cover and tap the cartridge a few times to evenly distribute any remaining toner. If symptoms persist, replace the toner cartridge.
	The paper is not suitable for the printer unit.	Use recommended paper.
Printing is light.	The toner cartridge is not properly seated.	Reinstall the toner cartridge.
	The toner is low.	Open the top cover and tap the cartridge a few times to evenly distribute any remaining toner. If symptoms persist, replace the toner cartridge.
	The paper is moist.	Use paper stored in proper temperature and humidity conditions.
	The paper is not suitable for the printer unit.	Use recommended paper.
	Thickness and type of paper are inappropriate.	Set a proper value for Media Weight and Media Type in the Paper Setup menu, or set one value thicker for Media Weight.
	Recycled paper is being used.	Set one value thicker for Media Weight in the Paper Setup menu.
Partially faded images. White spots and lines appear in solid printing.	Paper is moist or dry.	Use paper stored in proper temperature and humidity conditions.

SYMPTOMS	POSSIBLE CAUSES	STEPS TO TAKE
Vertical lines appear.	The image drum cartridge is damaged.	Replace the image drum cartridge.
	The toner is low.	Open the top cover and tap the cartridge a few times to evenly distribute any remaining toner. If symptoms persist, replace the toner cartridge.
Horizontal Lines and spots appear periodically.	When the interval is about 94mm (4in), the image drum (the green tube) is damaged or dirty.	Wipe it lightly with a soft cloth. Replace the image drum cartridge when it is damaged.
	When the interval is about 42mm (1.5in), there may be foreign particles in the image drum cartridge.	Open/close the top cover, and print again.
	When the interval is about 87mm (3.5in), the fuser unit is damaged.	Replace the fuser unit.
	The image drum cartridge has been exposed to light.	Replace the image drum cartridge if the problem is not resolved.
White area of paper is lightly stained.	Paper contains static.	Use paper stored in proper temperature and humidity conditions.
	Too thick paper is used.	Use thinner paper.
	The toner is low.	Open the top cover and tap the cartridge a few times to evenly distribute any remaining toner. If symptoms persist, replace the toner cartridge.
Periphery of the letters is smudged.	The LED head is dirty.	Wipe the LED head with a soft, lint-free cloth.
Toner comes off when it is rubbed.	The thickness and type of the paper are incorrectly set.	Set the correct value of Media Type and Media Weight in the Printer menu or set one value thicker for Media Weight.
	Recycled paper is used.	Set one value thicker for Media Weight in the Printer menu.
Glossiness is not uniform.	The thickness and type of the paper are incorrectly set.	Set the correct value of Media Type and Media Weight in the Printer menu or set one value lighter for Media Weight.

## Dealing with unsatisfactory copying

As well as the suggestions provided in "Dealing with unsatisfactory printing" on page 163, ensure that the scanner unit glass is clean at all times. Refer to "...the document glass" on page 149.

## **Fax problem checklist (MB470 MFP & MB480 MFP)**

If a problem occurs, read through the list of problems and solutions before calling for service.

### **The MFP will not dial a telephone number.**

Check the power cable and wall outlet. Make sure that the telephone line (not external telephone or handset) is connected to the LINE socket on the back of the machine. If an external telephone is installed, lift the handset and check for a dial tone. If there is no dial tone, there may be a problem with the telephone line. If there is a dial tone, the MFP may be using the wrong dialling method (pulse or tone) for the region. If alternating tones are heard instead of dialling pulses and the region uses pulse dialling, change the call parameters.

The display shows a communications error. This indicates any of a number of problems:

- The MFP may be incompatible with the remote machine, or the remote machine may not be able to perform the function requested of it such as polling or confidential faxing.
- The remote machine may also be out of paper or experiencing a paper jam.
- Bad telephone line conditions can also cause communication errors. Try sending the fax again and check to make sure that the correct telephone number is being dialled.
- If a prefix number must be dialled to get an outside line, or if the call is to an international destination, a pause may need to be entered after the dial prefix or international dialling code to tell the machine to wait for a dial tone. If there are frequent problems communicating with a particular remote machine, try programming the telephone number into a speed dial key, and then change the parameters for that key.
- Lastly, either the local or remote machine may require servicing. Try sending a fax to another location to check the local MFP.

### **Faxing is possible but the image of the document printed by the remote machine is very poor.**

If the faxed document has small type, complex illustrations, photos, or is very light or very dark, try changing the fax quality and density settings. Copy the document on the machine to determine how it will transmit. The problem may be caused by telephone line interference. Try sending the document again later.

### **Fax sent but received message was completely blank.**

Make sure that the document is loaded correctly before faxing; with text face UP in the ADF or face DOWN on the glass.

### **Image of received fax is very poor.**

Try making a copy of a document on the local machine to make sure it is working properly. If there is still a problem, contact the person sending the fax and ask them to change their fax quality and density settings. Ask the person to make a copy of the document on their machine to ensure that it is working properly. Then ask them to send the fax again.

### **Dialling was tried with a Speed Dial/ Group Dial number but nothing happened.**

Make sure that the Speed Dial/ Group Dial number being used is programmed correctly. When dialling a two or three digit number, be sure press # or \* before entering the number.

### **Documents received are light or have vertical streaks on them, and MFP is not out of toner.**

Lift the top cover and gently wipe the lens surface of the MFP's LED array. Then check to see if the toner or image drum need replacing (see "Replacing consumable items" on page 137).

### **MFP is set for delayed transmission but it did not send.**

Check the display to make sure that the MFP is set to the correct time and date (see "Clock Adjustment" on page 57).

### **MFP is connected to a PBX but it is not possible to dial out.**

Be certain that the dial prefix is entered before the telephone number for each number dialled or programmed into the machine. Additionally, the machine must be programmed for PBX operation before it will work with a PBX (see "Connecting to a PBX" on page 67 ).

### **MFP always answers before it is possible to use the external telephone.**

If an external telephone is connected, change the MFP's ring response setting.

### **Faxes received sometimes look distorted.**

If the document received is wider or longer than the paper loaded in the paper tray, the machine automatically reduces the width or length of the document so that it will fit on the paper. This type of problem could also be communication related.

# Specifications

## General

ITEM	SPECIFICATION
Dimensions, W x D x H	MB460 MFP, MB470 MFP: 17.6 x 17 x 19.7 inches (447 x 432 x 500 mm)  MB480 MFP: 17.6 x 17 x 20.8 inches (447 x 432 x 529 mm)
Weight, approximate	MB460 MFP: 37.4 lbs. (17 kg) MB470 MFP: 40.8 lbs. (18.5 kg) MB480 MFP: 41.9 lbs. (19 kg)
Power source	120V, 50/60 Hz $\pm$ 2% 220-240V, 50/60Hz $\pm$ 2%
Power consumption	Operating: 800W max. Normal operating: 500W Stand-by: 100W Power save mode: 10W max.
Noise	Operating: 56 dBA Standby: 32 dBA
Temperature	50 to 90°F (10 to 32°C)
Humidity	20% to 80% RH

# Scanning Specifications

ITEM	SPECIFICATION
Image sensor	Colour CCD
Light source	Cold Cathode Fluorescent Lamp (CCFL)
ADF - Simplex	50 sheets (60 ~ 105 g/m <sup>2</sup> )
Optical resolution	Flatbed: 1200 x 600 dpi ADF: 1200 X 300 dpi
Scanner life Flatbed ADF	50,000 pages or 5 years 240,000 pages or 5 years.
Scan area Flatbed ADF	105 mm x 148 mm ~ 215.9 mm x 296.9 mm 105 mm x 148 mm ~ 215.9 mm x 355.6 mm
Document size Flatbed ADF	B5, A5, A4, Letter B5, A5, A4, Letter, Legal 13, Legal 13.5, Legal 14
Document thickness Flatbed ADF	11 mm 60 - 105 g/m <sup>2</sup>
File Format Scan to Email/Server Actkey	PDF, TIFF, JPEG PDF, TIFF, JPEG, BMP, PCX, GIF, TGA, PNG, WMF, EMF, Multi-PDF, Multi-TIFF
Driver	TWAIN, WIA
Paper feed	ADF: Face up

## Copy Specifications

ITEM	SPECIFICATION
Speed	ADF: 21 cpm (copies per minute), A4, 300 dpi 22 cpm, Letter, 300 dpi
Number of copies	Up to 99
Resolution	Scan: 600 x 600 dpi, 300 x 300 dpi Print: 600 x 600 dpi
Paper size Flatbed ADF	B5, A5, A4, Letter B5, A5, A4, Letter, Legal 13, Legal 13.5, Legal 14
Density	7 levels
Copy Mode	Mixed, Photo: 300 dpi Scan/ 600dpi Print Hires. Mixed, Hires. Photo: 600 dpi Scan/ 600dpi Print
Input tray	Tray 1/MP Tray/Tray 2 (optional)
Edge erase	Top, Bottom, Left, Right Edge: 0 ~ 1 inch
Margin shift	Bottom, Right direction: 0 ~ 1 inch
Paper saving (N-in-1)	2-up, 4-up
Collate	64 MB standard memory: 25 pages A4 (ITU-T#1) 320 MB optional memory: 50 pages A4 (ITU-T#1)

# Network Specifications

ITEM	SPECIFICATION
Connectivity	Ethernet 100Base-TX/10Base-T auto-negotiation with RJ-45 connector
Network protocol	TCP/IP: Network layer - ARP, IPv4/v6, ICMPv4/v6 Transport layer - TCP, UDP Application layer - LPR, FTP, TELNET, HTTP (except IPP), IPP, DHCP/BOOTP, SMTP, WINS, SNMPv1/v3, DNS, DDNS, UPnP, Bonjour, POP3, SNT, WSDPrint, Kerberos NetBEUI: SMB, NetBIOS, CIFS, WINS Netware: Remote printer mode (max. 8 print servers) Print server mode (max. 8 file server, 32 queues) Encrypted password support (in print server mode) NetWare6J/5J/4.1J (NDS, boundary) SNMP ETHERTALK: ELAP, AARP, DDP, AEP, NBP, ZIP, RTMP, ATP, PAP IEEE802.1X IEEE802.1X: EAP-TLS, PEAP
Supported browsers	Microsoft IE 5.5 or higher Netscape Navigator 6.0 or higher
Configuration requirement	IP address Subnet mask Gateway SMTP server/POP3 server FTP server Web server

## Fax Specifications (MB470 MFP and MB480 MFP only)

ITEM	SPECIFICATION
Circuits	PSTN, PBX line
Compatibility	ITU-T G3/Super G3
Transmission speed	3 seconds per page
Line interface	Dual RJ-11C (Line and TEL)
Compression method	MH, MR, MMR
Resolution:	Standard: 200 x 100 dpi Fine: 200 x 200 dpi Photo: 200 x 200 dpi Extra Fine: 200 x 400 dpi
Speed dials	100 (max. 32 digits each location)
Group dial	max 10 groups
Auto redial	Yes
One touch dial	5 x 2 location (with shift key)
Sender ID	Yes (max. 32 characters)
Transmission	Broadcast: Yes (max. 100 transmissions)
Receive	Delayed: Yes (up to 5 transmissions; up to one month from current date/time)
	Memory: Yes, receives even when printer error or paper out situation occurs Remote: <ul style="list-style-type: none"> <li>• Windows 2003 Active Directory</li> <li>• Windows 2000 Active Directory</li> <li>• Windows NT 4.0 + MS Exchange 5.5</li> <li>• Lotus Notes R5</li> </ul>
Printer life	200,000 pages or 5 years
Duty cycle	MB460 MFP, MB470 MFP: 50,000 pages per month max.  MB480 MFP: 70,000 pages per month max.

# E-mail Specifications

ITEM	SPECIFICATION
Communication protocol	SMTP, MIME, POP3
File formats	PDF, M-TIFF, JPEG
Default file format	PDF
Resolution	100, 150, 200, 300 dpi (400, 600 dpi 1 bit mono only)
Default resolution	B&W: 200dpi Grey/Color: 150dpi
Address book volume	Max. e-mail addresses: 100 Groups: 20
Multi "Subject" registration	Yes, 5 kinds of "Subject"
Job Build Scanning	Yes
Separation limit	1MB, 3MB, 5MB, 10MB, 30MB, No limit
Mail server authentication	SMTP-Auth, POP3
Supported mail server application	Lotus Mail Server 5.0 MS Exchange Server 2000 RedHat 7.0 SendMail
Supported LDAP server	Windows 2003 Active Directory Windows 2000 Active Directory Windows NT 4.0 + MS Exchange 5.5 Lotus Notes R5
Supported mail application	Microsoft Outlook 2000 Microsoft Outlook Express 5.0 Microsoft Outlook Express 6.0 Netscape Messenger 4.7 Netscape Messenger 4.73 Eudora 4.3.2J Lotus Notes R5 Apple Mail

# Filing Specifications

ITEM	SPECIFICATION
Communication protocol	FTP, CIFS
File formats:	PDF, M-TIFF, JPEG
Default file format	PDF
Resolution	100, 150, 200, 300 dpi (400, 600 dpi 1 bit mono only)
Default resolution	B&W: 200dpi Grey/Color: 150dpi
Max. number of File server settings	20
Job Build Scanning	Yes

# Printing Specifications

ITEM	SPECIFICATION
Speed	Letter: 30 ppm A4: 28 ppm
Resolution	MB460 MFP <ul style="list-style-type: none"> <li>• 600 x 600 dpi</li> <li>• 1200 x 600 dpi</li> <li>• 2400 x 600 dpi (half speed)</li> </ul> Optical: 600 dpi  MB370 MFP and MB480 MFP <ul style="list-style-type: none"> <li>• 1200 x 1200 dpi</li> <li>• 600 x 600 dpi</li> </ul> Optical: 1200 dpi
Memory	64 MB standard, upgradeable to 320 MB max.
Paper capacity at 20 lb. US Bond (75 g/m <sup>2</sup> )	Main Tray <ul style="list-style-type: none"> <li>• MB460 MFP/MB470: 250 sheets</li> <li>• MB480: 530 sheets</li> </ul> Multi Purpose Tray <ul style="list-style-type: none"> <li>• MB460 MFP: Manual single sheet feed</li> <li>• MB470 MFP &amp; MB480 MFP: 50 sheets</li> </ul> Optional 2nd Tray <ul style="list-style-type: none"> <li>• 530 sheets</li> </ul>
Paper weight	Main Tray <ul style="list-style-type: none"> <li>• 16 to 32 lb. US Bond (60 ~ 120 g/m<sup>2</sup> )</li> </ul> Multi Purpose Tray <ul style="list-style-type: none"> <li>• 16 to 43 lb. US Bond (60 ~ 163 g/m<sup>2</sup>)</li> </ul> Optional 2nd Tray <ul style="list-style-type: none"> <li>• 16 to 32 lb. US Bond (60 ~ 120 g/m<sup>2</sup>)</li> </ul> Duplex Printing <ul style="list-style-type: none"> <li>• 16 to 28 lb. US Bond (60 ~ 105 g/m<sup>2</sup>)</li> </ul>
Paper output	150 sheets in face down (top) stacker @ < 20 lb. US Bond (75 g/m <sup>2</sup> )
Printer life	200,000 pages or 5 years

ITEM	SPECIFICATION
Duty cycle	MB460 MFP, MB470: <ul style="list-style-type: none"> <li>• 50,000 pages per month max.</li> </ul> MB480: <ul style="list-style-type: none"> <li>• 70,000 pages per month max.</li> </ul>
Toner life	MB460 MFP: <ul style="list-style-type: none"> <li>• 3500 pages</li> <li>• 7000 pages</li> </ul> MB470: <ul style="list-style-type: none"> <li>• 3500 pages</li> <li>• 7000 pages</li> </ul> MB480: <ul style="list-style-type: none"> <li>• 3500 pages</li> <li>• 7000 pages</li> <li>• 12000 pages</li> </ul>

# Appendix A - Moving and transporting

## Moving your MFP

---

### Note

Lock the scanner before moving the MFP.

---

1. Turn off the MFP and disconnect or remove the following:
  - Power cord
  - Printer cable
  - Paper in the paper cassette
2. Move the MFP to the new location.

### **Warning!**

**This product is heavy; a minimum of two people are required to lift it safely.**

---

### Note

Be sure to unlock the scanner before turning on the MFP.

---

## Transporting your MFP

### **Warning!**

**Your MFP is a precision machine and can be damaged during transportation if packaged incorrectly.**


---

### Notes


- If your machine is equipped with the additional paper tray remove it before transporting.
  - Lock the scanner before transporting the MFP.
- 

1. Turn off the MFP and disconnect or remove the following:
  - Power cord
  - Printer cable
  - Paper in the paper cassette

2. Lift the scanner.




3. Press the cover release (a) and open the top cover (b) fully.



***warning!***

**If the MFP has been powered on, the fuser will be hot. This area is clearly labelled. Do not touch.**


4. Lift the image drum along with the toner cartridge out of the MFP and place it on a flat table.



***Caution!***


The green image drum surface at the base of each cartridge is very delicate and light sensitive. Do not touch it and do not expose it to normal room light for more than 5 minutes. Never expose the drum to direct sunlight or very bright room lighting.

5. Place the drum and cartridge in a black bag plastic bag.



6. Re-install the image drum along with the toner cartridge back into the MFP.
7. Close the top cover and press down firmly so that the cover latches closed.

8. Gently lower the scanner.



9. Protect the MFP with cushion pads and put it in a box.

---

**Note**

It is recommended that you use the original box and packaging if available.

---

***Warning!***

**This product is heavy; a minimum of two people are required to lift it safely.**

---

**Note**

Be sure to unlock the scanner before turning on the MFP.

---